

Tune Up Procedure

There is no tune-up procedure for this device, the power level is set at the factory and there are no provisions for a user to adjust the power level.