


MODEL 99109/06434RC USER'S MANUAL


A. CONTROLLER

1. UNSCREW THE BATTERY COMPARTMENT COVER.
2. PLACE ONE 9V. ALKALNE BATTERY INSIDE THE COMPARTMENT AS THE ENGRAVED POSITION.
3. PUSH THE BUTTON FOR FORWARD AND REVERSE.



B. CAR

1. UNSCREW AND OPENT THE BATTERY COMPARTMENT COVER AT THE CHASSIS THE CAR.
2. PLACE FOUR "AA" OR "UM-3" SIZE ALKALINE BATTERIES INTO THE BATTERY COMPARTMENT AS THE LABEL POSITION.
3. DO NOT MIX NEW AND OLD BATTERIES TOGETHER.
4. DO NOT MIX ALKALINE, LITHIUM OR OTHER KIND SAME SIZE BATTERIES TOGETHER.
5. DO NOT USE RECHARGEABLE BATTERIES.
6. ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
7. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
8. ALWAYS REMOVE OUT EXHAUSTED OR DEAD BATTERIES FORM THE PRODUCT.
9. WHEN STORING FOR A LONG PERIODS OF TIME, REMOVE OUT THE BATTERIES.



NOTE:

The users manual or instruction manual for on intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment