


2. Description for GVP unit

❖ Front View ❖



- **CCD Camera:** Capture your image.
- **LCD Screen:** Display the other party and your image
- **Power Indicator:** When Power Indicator is on, it indicates that power is connected to videophone.
- **Monitor Indicator:** Light when LCD Screen is activated or blinking at Auto-Answering(Remote Surveillance) mode
- **Speaker:** You can hear the other party's sound through this.
- **Keypad :**
 - ① Number / Alphabet
Entering phone numbers & characters
 - ② For switching number key / Alphabet key
 - ③ Exit GUI mode
 - ④ Requesting video communication in audio mode
 - ⑤ For switching various screen mode
 - ⑥ Block the outgoing audio
 - ⑦ Block the outgoing video
 - ⑧ For hand-free dialing
 - ⑨ Up/Down or Left/Right option select
 - ⑩ Enter the GUI mode or Confirm the selected mode