

INSIGNIA™

QUICK SETUP GUIDE

Color Changing Computer Speakers with Bluetooth

NS-2810BT

PACKAGE CONTENTS


- Stereo speakers (2)
- AC adapter (100 - 240V)
- 5 ft. (1.52 m) 3.5 mm to 3.5 mm audio cable
- *Quick Setup Guide*

FEATURES


- Eight color modes (blue, green, red, purple, yellow, light blue, repeating six colors, and off) help set the mood
- 5W RMS (2.5W per channel) produces quality sound
- Bluetooth connectivity wirelessly streams audio from your Bluetooth-enabled devices
- 3.5 mm input jack lets you connect to other external sound sources
- Headphone jack provides an easy connection option for private listening

Flat size (W×H): 12.44 × 11.69 in (315.976 × 296.93 mm.)
Final folded size: 4.14 × 11.69 in (105.156 × 296.93 mm.)


Front



Back



CONNECTING POWER



- Plug your speaker's USB cable into the AC adapter, then plug the adapter into a power outlet.

TURNING YOUR SPEAKERS ON AND OFF

- Rotate the knob clockwise to turn on your speakers and adjust the volume. Rotate counter-clockwise to turn off your speakers.

CONNECTING WITH BLUETOOTH

- 1 Make sure that your Bluetooth device is turned on and within 33 feet (10 meters) of your speakers.
- 2 Turn on your speakers. The status LED blinks blue to indicate that they are in pairing mode. If the status LED is red, press the **Source** button once to switch to Bluetooth mode.
- 3 Turn on your Bluetooth device, then turn on Bluetooth. Set your device to pairing mode, then select **Insignia NS-2810BT**. See the instructions that came with your Bluetooth device for information about pairing.
- 4 If you are asked for a password, enter **0000**. When pairing is complete, the LED lights solid blue.

STATUS LED

STATUS LED	DESCRIPTION
Blinks blue	Speakers are in pairing mode
Solid blue	Speakers are paired
Solid red	AUX mode

RECONNECTING WITH A PREVIOUS DEVICE


- Make sure that the last paired Bluetooth device is near your speakers.
- When your speakers are on, they automatically search for and try to connect to the last paired device.

FORCE PAIRING AND CONNECTING WITH A NEW DEVICE

- If you have paired your speakers to a device and want to pair with a different device, press and hold the **Source** button for three seconds until the blue LED begins blinking. Search your new device's Bluetooth list for **Insignia NS-2810BT**, then tap to pair and connect.

USING A WIRED CONNECTION

- 1 Connect an external sound source, such as an MP3 player, by plugging the included audio cable into the **AUX** jack on the back of the control speaker and the sound source.



- 2 Press the **Source** button to enter AUX mode. The status LED lights red.

