




CHARGING PROCEDURE:

1. Turn the switch on the bottom of the car to OFF/CH mode

2a.




- 2b. Snap into the slot at the car rear



- 2c. Press and push forward to fasten

- 2d. Press the charge button "⏻" to charge the vehicle. The RED light is on while charging.

3. Wait about 2 minutes for charging until the RED indicator turns OFF




4. ① Push the vehicle backward and front tilt up
② Take it off


5. Turn the car switch on the bottom of the car to "ON" mode to start playing.

6. Turn the switch of the car to OFF/CH position when not in use.

BATTERY INSTALLATION:



- UNSCREW THE BATTERY COVER WITH A PHILLIPS SCREWDRIVER AND SLIDE OUT.



- INSERT 4 "AAA" BATTERIES INTO THE BATTERY COMPARTMENT. MAKE SURE THE ENDS OF THE BATTERIES OF POSITIVE (+) AND NEGATIVE (-) MATCHING THE MARKINGS ON THE BATTERY COMPARTMENT.

- CLOSE AND TIGHTEN THE BATTERY COVER WITH A PHILLIPS SCREWDRIVER BY REVERSING THE PROCEDURES AS SHOWN PER PICTURE ①

HOW TO OPERATE:

1. Turn ON/OFF switches on bottom of car
2. Extend transmitter antenna to full length when in use.
3. **FORWARD DRIVE:** Push left joystick to position 3 to move forward. Joystick will automatically return to Neutral position when released.
4. **REVERSE DRIVE:** Move left joystick to position 4 to move in reverse. Joystick will automatically return to Neutral position when released.
5. **LEFT/RIGHT STEERING:** Move right joystick left or right for desired direction while operating Forward/Reverse function.

