


Model No.: HS



Cursor 0	925.62	72.32	☒	☒	☒
Cursor 1	925.05	74.41	☐	☒	☒

Marker Delta

1.57 MHz

-0.59 dB

RB

30 kHz

VB

30 kHz

Center Freq.

925.850 MHz

ATTEN

10 dB


REF LVL

110.000


SPAN

5.000 MHz

Model No.: HS



Model No.:



Cursor 0	926.29	81.56	☐	☐	☐
Cursor 1	925.07	74.73	☐	☐	☐

Marker Delta

1.22 MHz

6.83 dB

RB

30 kHz

VB

30 kHz

Center Freq.

926.000 MHz

ATTEN

10 dB


REF LVL

110.000

SPAN

3.000 MHz

Model No.:



Cursor 2	926.62	71.19	☐	☒	☐
Cursor 1	925.07	74.59	☐	☒	☐

Marker Delta

1.55	MHz
-3.40	dB

RB

30kHz

VB

30kHz

Center Freq.

926.000 MHz

ATTEN

10 dB

REF LVL

110.000

SPAN

3.000 MHz