

Preface

Introduction


Bluetooth technology is a new generation wireless communication system, which consumes low power and transmits data among different products within a short distance; thus, Bluetooth wireless communication device will connect various digital devices without any wired transmission circuit. Your Bluetooth headset can communicate with other Bluetooth devices within 10 meters (33 feet) .

Note : Bluetooth headset simultaneously supports both HS and HF profiles to match more product functionalities and compatibilities.

Specification

- Product feature : wireless transmission.
- Talk time : less than 6 hours.
- Standby time : less than 150 hours.
- Effective range : 10 meters.
- Compatible headset : Headset supporting HS/HF profile.

Appearance Description



- 1.Indicator Light : Provides visual cue about headset status.
- 2.Volume down key : Adjusts speaker (receive) volume down.
- 3.Volume up key : Adjusts speaker (receive) volume up.
- 4.Multi-function button (MFB) : Controls several headset functions.
- 5.Microphone : Picks up your voice input.
- 6.Speaker : Plays the sound you receive on the call.
- 7.Earhook : Attaches headset to ear.
- 8.Charging : Connects the plug to your battery charger.
- 9.Trimming hole : Connects the trimming to the trimming hole.

Charging

Introduction


Before your first time using Bluetooth headset, please charge for 24 hours to make sure that your headset is fully charged. Afterward, if you hear five short tones from the headset every 20 seconds, that means that your battery is running low and should be immediately charged for 1 ~ 1.5 hours. However, please not charge your headset over 24 hours again.

Note : After you use your headset for a while, the battery will gradually deteriorate and then cause the charging time to increase; this is a normal phenomenon. The more you use your headset, the less the standby time will be °

How to charge

SETUP 1


Plug the charger into the charging port. While headset is being charged, the indicator light is lighting up.



SETUP 2

After headset is fully charged, the indicator light will be off ; at this time you can remove the charger from the outlet and remove charger from headset.

Note : Only by certified service engineer can the battery be dismantled or replaced. If the headset is under appropriate use, the battery will work for a long time. New battery or the one, which has not been used for a long time, will possess lower electricity capacity in the first few uses.



Turning the Headset On or Off

Turning on the Headset

Simultaneously press both the multi-function button (MFB) and volume up / down button for more than 2 seconds; then the indicator light on Bluetooth headset will light up. After 3 seconds, the indicator light will start blinking and you can use your headset now.

Turning off the Headset

Simultaneously press both the multi-function button (MFB) and volume up / down button for more than 2 seconds until you see the indicator light changes from blinking to lighting; then Bluetooth headset will be off immediately .

Pairing your Headset and Phone

First, you have to make sure that your phone is Bluetooth-supported, and then put your phone and headset within the effective range (10 m) to make them enter pairing mode.

1. Turn on both your headset and phone.
2. Press volume-up or volume-down button for 2 seconds until the indicator light lights up. This means that both devices enter pairing mode.
3. Select " Helios " from the phone screen to pair headset and phone.
4. Afterward, you will be asked to enter the password . Please enter 0000. If pairing is successful, the indicator light on headset will rapidly blink 5 times.
5. If you want to leave the pairing mode, please press the side button (volume-up or volume-down) for 2 seconds until the indicator light is blinking .

Note : If your Bluetooth headset can't search the headset within 1 minute, this means that the pairing is unsuccessful. Please repeat the stated procedures above.