

Block Diagram

Name: Weathermate, Weathermate Remote Transmitter, & Weathermate Remote Receiver
Model #: WM12-x, WM-RT & WM-RR




Figure 1 - Block Diagram of System Configuration