

Figure 3
Removed Back Cover of Case, Frame of Internal




Figure 4
Frame of Internal (Removed Shielding Plate of Main Board)




Figure 5
Frame of Internal (Removed Main Board, Adjustment Board & Power Switch Board)



Figure 6
Shielding Plate of LCD Panel




Figure 7
Front Cover of Case (Internal View, Adjustment Board & Power Switch Board)





Figure 8
Main Board (Component Side)



ATM-G99179

Figure 9
Main Board (Solder Board)



ATM-G99179





Figure 10
Inverter Board of LCD Panel (Component Side)

Figure 11
Inverter Board of LCD Panel (Solder Side)

ATM-G99179






Figure 12
LCD Panel (Front Side)

ATM-G99179



Figure 13
LCD Panel (Back Side)

Figure 15
Base of Monitor (Appearance, Front Side)




Figure 16
Base of Monitor (Frame of Internal)




Figure 17
USB Control Board (component Side)




Figure 18
USB Control Board (Solder Side)




Figure 22
Power Adapter (AC Inlet & PCB View, Component Side)




Figure 23
Power Adapter (AC Inlet & PCB View, Solder Side)

AIM-000119




Figure 21
Power Adapter (Removed Case Cover, Internal View)

