


UF-434 WIRELESS STEREO HEADPHONE OPERATING

OPERATING CONTROLS

WIRELESS STEREO HEADPHONE


A. Right side (R)

1. Power ON/OFF switch
2. Led indicator
3. 3 Channels select switch & Auto mute
4. Volume control
5. Headphone earpad
6. Luxurious headband
7. Battery compartment



TRANSMITTER

1. Power ON/OFF switch
2. Power-On indicator
3. Power input jack
4. Audio input jack
5. 3 Channel select switch



ACCESSORIES

1. AC adaptor (18V output) for Transmitter




2. "Y" adapter cable



3. Stereo audio cable



4. Stereo adaptor plug (3.5mm to 6.5mm)



INSTALLATIONS:

Transmitter

1. Plug the AC adaptor into any convenient electrical wall outlet then connect the cable coming from the "AC adaptor" into the back of the transmitter
2. Turn on the power ON then the LED will illuminator for green light.
3. Select one of the channels to transmission (example, CH1)
4. Hooking up the supplied the cables depending on your audio systems and available audio output jacks to your Audio sources (TV, VCD, DVD or PC etc.) If the single end of the "Y" cable is too small to fit into the headphone output jack, use the headphone adaptor plug to complete the connections.

Headphone

1. Open the battery compartment lid and insert 3pcs of "AAA" batteries. Then cover the battery compartment lid. Make sure that the battery are inserted as indicated with the polarity marking inside the battery compartment
2. Turn on the Power ON switch then illuminated green LED light indicator is ON. Select one of the channels to receive (example, CH1). If the LED turns RED, please select the channel as the same as the transmitter.
3. Adjust the headset's volume level to a comfortable level

P.S: Headphone is built in AUTO MUTE function when it is not able to receive audio signal or receiving is not good enough. Then the headphone will automatic to stop playing music until the receiving better.