


INDEX PLACEMENT


MARK	DESCRIPTION
A	AUDIO SECTION
B	DC SUPPLY SECTION
E	EXT.REMOTE
F	USB SECTION
G	SIRIUS SECTION
IP	IPOD SECTION
J	JENSEN BUS SECTION
K	FRONT BOARD SECTION
M	MCU SECTION
N	CONNECT SECTION
P	PA SECTION
S	SD CARD SECTION
T	RADIO TUNER SECTION
V	CD/DVD SECTION
W	SUB_WOOFER


01 : INDEX_PLACEMENT
 02: AM/FM/WB/SIRIUS
 03 : MCU/EPROM/RTC MEMORY/TO KB CON
 04: POWER/AUDIO_AMP/F/R.RCA
 05: USB/IPOD/CD_CONNECT/SD/ Bluetooth
 06: JENSEN_BUS/PA
 07: AUDIO SWITCH


note:
 mark in front of the component indicate
 the meaning in the schematics.


MODEL: JHD3510C	DRAWING NO: JHD3510C-MB01-S01-00
PART NAME: INDEX_PLACEMENT	REV: DATE REV: DATE
DESIGNER: .01	03
CHK/DATE: .02	04
APP/DATE:	AR Electronics Co., Ltd













MODEL: JHD3510C	DRAWING NO: JHD3510C-MB01-S01-00			
PART NAME: AUDIO_SWITCH	REV: 01	DATE: 2015.10.13	REV: 03	DATE:
DRN/DATE:	02		04	
CHK/DATE:				
APP/DATE:				
AR Electronics Co., Ltd				





MODEL: JHD350C	DRAWING NO: JHD350C-CD01-S01-00
PART NAME: JHD350C-CD	REV: DATE REV: DATE
DRN/DATE: 01	01
CHK/DATE: 02	02
APP/DATE:	

AR Electronics Co., Ltd.