




J4-1 to J4-5 is connected to volume controller.
 J4-6 is connected to Mic.
 J2 is connected to Antenna.

COMPANY: JAUNTIWAY TOY COMPANY		
DRAWN: Ludichun	DATED:	
CHECKED:	DATED:	REV:
APPROVED:	DATED:	CODE:
TITLE: Transmitter #80645		SHEET OF