

TRU kids brands™		File Name:US_F20_FL_5F633F7_IM_FIN	
		Mfr#: 5F633F7 Skn#:	
Studio: TRUGSOHK		Vendor: Kidztech Toys	
Product Description:		1:12 RC CARS IM	
Flat Art Size: A4 size		Coating:	
Packaging Dimension:	Width:	PKG color	K
	Height:		die-line
	(if box)Depth:	Insert color	
Raster Effect:	300 PPI	Date:	23 JUNE 2020
(PDP) Primary Display Panel Size:			
Warning Size/Legal Panel:			

*REMINDER: Open space above UPC on packaging (and end of sewn-in-label if applicable) is the DATE CODE STAMP area. Please refer to TRUGPSQC Manual for date code requirements detail.

A4 size (Black & White) - English - FRONT



CAUTION-ELECTRIC TOY:
Not recommended for children under 6 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

CAUTION-SUPERVISION REQUIRED-ELECTRIC TOY:
ELECTRIC TOY-UNPLUG WHEN NOT IN USE.
INPUT: 100-240V-50/60Hz OUTPUT: 6.4V==600mA

Charger (Included)

6.4V 500mAh For Vehicle (Included)

9V 1 x 9V For Transmitter (Included)

6.4V

9V

Charger

6.4V

Battery Requirement

- Vehicle: 1 x 6.4V rechargeable battery pack.
- Transmitter: 1 x 9V battery

The Included 6.4V rechargeable battery pack is NOT charged prior to shipment and must be charged at least 2 hours before the first use.

Charging the Rechargeable Battery Pack for the Vehicle:

- Plug the Charger into a standard AC socket.
- Insert the 6.4V rechargeable battery pack securely into the charger (as shown).
- Be sure the arrows are properly matched.
- Allow battery to charge for minimum of 2 hours on the initial first charges. Subsequent charges require only 2 hours.
- Play time approximately 15 minutes depending on terrain and driving style.
- The Charger is intended to be correctly orientated in a vertical or floor mount position.
- When charging is completed, unplug the charger from the AC socket.
- Release the 6.4V rechargeable battery pack from the battery charger.

IMPORTANT: It is normal for the battery pack to become warm after charging and/or use. Be sure to allow the battery pack to cool down before using or recharging. Recharging a warm battery pack will greatly reduce the battery life.

IMPORTANT: FOR MAXIMUM PERFORMANCE, YOU MUST FULLY CHARGE BATTERY PACK BEFORE FIRST TIME USE.

ATTENTION FOR PARENTS:
The Charger & 6.4V Battery Pack need to be periodically examined for potential hazards. Any potentially hazardous parts need to be repaired or replaced.

Contents

- RC Vehicle (Vehicle) x 1 • RC Transmitter (Transmitter) x 1
- Antenna for RC Transmitter x 1 • Instruction Manual x 1
- 6.4V rechargeable Battery Pack x 1 • Charger x 1 • 9V Battery x 1

Battery Precaution

- The 6.4V rechargeable battery pack must be charged before use by utilizing the battery charger which included
- Do not overcharge the battery pack. Do not charge for more than 6 hours
- Do not charge the battery pack if it shows leakage, corrosion, or has loose or exposed wires or other damage
- Do not cover the battery pack with any sort of materials while charging
- Do not touch the battery pack when it is hot. Wait until the battery pack cools before installing it in the Vehicle or before recharging
- Do not dispose of the battery in fire
- Do not dismantle the battery or charger, and do not out the battery or charger cables
- The battery pack will be warm after charging, and hot after use in a vehicle
- The supply terminals are not to be short-circuited
- Rechargeable batteries are to be removed from the toy before being charged
- Rechargeable batteries are only to be charged under adult supervision
- Battery replacement must be only made by adults
- The Transformer (charger) is not a toy
- Charge only type (500mAh Max.) rechargeable battery packs. Other types of transformers may burst causing injury to persons and damage. This power unit is intended to be correctly orientated in a vertical or floor mount position. This charger is intended to be used for charging 6.4V rechargeable battery pack with capacity 500mAh Max. It cannot be used for charging non-rechargeable batteries. Regular examination of battery charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the charger or battery pack charge until such damage has been repaired. Note that the 9V battery is non-rechargeable and is not to be recharged. Only batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor.
- Exhausted batteries are to be removed from the product.

Battery and Antenna Installation For Vehicle (Fig. 1 and Fig. 2)

- Switch the power OFF
- Unscrew the screw on the battery cover
- Open the battery cover
- Plug 6.4V battery pack with correct polarities (+/-) as shown inside the battery compartment
- Close the battery cover
- Tighten the screw on the battery cover

Fig. 1

Vehicle - BUGATTI VISION GT

Fig. 2

Vehicle - Battery Installation

For Transmitter (Fig. 3 and Fig. 4)

- Switch the power OFF
- Unscrew the screw on the battery cover
- Open the battery cover
- Install 1 new 9V battery with correct polarity (+/-) as shown inside the battery compartment
- Close the battery cover
- Tighten the screw on the battery cover
- Insert the antenna into the top of Transmitter, tighten it by rotating clockwise (viewing from top of Transmitter)

Fig. 3

Transmitter

Fig. 4

Vehicle - Battery Installation

A4 size: (black & White) - ES -Front



PRECAUCIÓNJUGUETE ELÉCTRICO:
No recomendado para niños menores de 6 años. Al funcionar con electricidad, deben cumplirse los consejos de seguridad durante la manipulación y la utilización para evitar posibles descargas eléctricas.

ATENCIÓN: SUPERVISION NECESARIA.
JUGUETE ELÉCTRICO. DESCONECTAR CUANDO NO SE ESTÉ UTILIZANDO.
ENTRADA: 100-240V-50/60Hz SALIDA: 6.4V==600mA

Cargador (Incluido)

6.4V 500mAh para el vehículo (Incluido)

9V 1 x 9V para el transmisor (Incluido)

6.4V

9V

Cargador

6.4V

La batería recargable de 6.4 V NO se carga antes del envío a las tiendas y se deberá cargar al menos durante 2 horas antes de usar por primera vez.

Cargar la batería recargable de 6.4 V del vehículo:

- Enchufar el cargador a una toma de corriente normal.
- Ajustar la batería recargable de 6.4 V en el cargador (como se muestra). Asegurarse de que las flechas coincidan.
- Permitir que la batería se cargue al menos 2 horas durante las dos cargas iniciales. Para las cargas posteriores, bastará con 2 horas.
- Tiempo de juego aproximado 15 minutos según el terreno y estilo de conducción.
- El cargador está pensado para pensarse en posición vertical o en posición fija en el suelo.
- Una vez finalizada la carga, desenchufar el cargador de la toma de corriente.
- Retirar la batería recargable de 6.4 V del cargador.

IMPORTANTE: Es normal que la batería se caliente tras la carga y/o el uso. Asegúrese de dejar que la batería se enfríe antes de usarla o de recargarla. Si se recarga una batería caliente, se reducirá enormemente su vida útil.

IMPORTANTE:
PARA Función Máxima, NECESITA CARGADA LA BATERÍA COMPLETAMENTE ANTES DE COMENZAR A UTILIZAR ESTE JUGUETE.

Aviso para padres:
El cargador y la batería de 6.4 V se deben examinar periódicamente para detectar posibles peligros. Las piezas potencialmente peligrosas se deben reparar o sustituir.

Contenido

- Vehículo teledirigido (vehículo) x 1 • Transmisor de radiocontrol (transmisor) x 1
- Antena de transmisor de radiocontrol x 1 • Manual de instrucciones x 1
- Batería recargable de 6.4 V x 1 • Cargador x 1 • Pila de 9 V x 1

Precaución con las pilas

- La batería recargable de 6.4 V debe cargarse antes de usar con el cargador de batería incluido.
- No sobrecargar la batería. No cargar durante más de 6 horas.
- No cargar la batería si muestra pérdidas, corrosión o tiene cables expuestos o sueltos, o cualquier otro tipo de daño.
- No cubrir la batería con ningún material mientras se carga.
- No tocar la batería cuando está caliente. Esperar a que la batería se enfríe antes de colocarla en el vehículo y antes de volver a cargarla.
- No tirar la batería al fuego.
- No desmontar la batería ni el cargador y no cortar la batería ni los cables del cargador.
- Después de cargarse y de usarse en el vehículo, la batería estará caliente.
- Los terminales de suministro no deben entrar en cortocircuito.
- Las baterías o pilas recargables se deberán retirar del juguete antes de cargarse.
- Las pilas o baterías recargables solo se deberán cargar bajo supervisión de un adulto.
- La batería debe cambiarse un adulto.
- El transformador (cargador) no es un juguete.
- Solo puede cargar baterías recargables (de 500 mAh máx.). Otros tipos de pilas o baterías pueden explotar y causar lesiones o daños. Esta unidad de alimentación está pensada para pensarse en posición vertical o en posición fija en el suelo. El cargador está pensado para usarse con baterías recargables de 6.4 V con una capacidad máx. de 500 mAh. No puede usarse para cargar pilas no recargables. Examinar el cargador cada cierto tiempo en busca de daños en el cable, enchufe, estructura y otras piezas y, de encontrarse dichos daños, no se deberá utilizar el cargador o la batería hasta que se subsanen dichos daños. Tener en cuenta que la pila de 6 V del transmisor no es recargable y que no debe recargarse. Solo se deberán utilizar pilas del mismo tipo o de un tipo equivalente al recomendado. Si la transmisión no es buena, hay que cambiar la pila.
- Las pilas gastadas deben retirarse del producto.

Para el transmisor (Fig. 3 y Fig. 4)

- Apagar el juguete.
- Abajar el tornillo de la tapa de la pila.
- Apriar la tapa de la pila.
- Poner 1 pila nueva de 9 V con la polaridad correcta (+/-), tal como se indica dentro del compartimiento de la pila.
- Cerrar la tapa de la pila.
- Apriar el tornillo de la tapa de la pila.
- Insertar la antena en la parte superior del transmisor; apretar en el sentido de las agujas del reloj (visto desde la parte superior del transmisor).

Fig. 3

Transmisor

Fig. 4

Colocación de pila en el transmisor

BACK

How to Play

- Switch the Vehicle ON
- Use the Forward / Backward joystick (Fig.3) to drive the Vehicle forward and backward
- Use the Left / Right joystick (Fig.3) to control the Vehicle turning left or right
- If the vehicle does not run in straight line, adjust the Direction Adjustment on the vehicle chassis (Fig. 1)
- Play on smooth surface to have the optimum performance
- Remember to switch the power OFF for both the Vehicle, and Transmitter after using
- The optimum control range is up to 65 feet outdoors.

Performance Tips

- Do not drive on grass, dirt, sand, dusts, carpet or go through water
- Do not drive in windy or rainy weather
- Avoid direct impact the Vehicle with obstacles
- Switch the power OFF when not in use to prevent damage due to battery leakage
- Remove all batteries from the Vehicle and Transmitter when not in use for long period
- Keep fingers, hair and loose clothing away from wheels
- The operating range can be affected by a variety of factors
 - a) Low Voltage of batteries in Transmitter or Vehicle
 - b) Interference from other items that emit radio frequency signals
- Outdoor usage is recommended in order to get optimum control range
- Play with the vehicle on a clean and smooth surface
- Clean the battery compartment to make sure it is free from dust to prevent poor battery contact

Cautions

- Do not attempt to disassemble the Vehicle or Transmitter
- Do not operate the Vehicle with same frequency with other player(s) in same location. This can cause the vehicle to lose control.
- Make sure the batteries are installed with correct polarities (+/-) as shown inside the battery compartment
- Remove the package and take out all accessories before giving the Vehicle and Transmitter to child

FCC label compliance statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Recent or relocate the receiving antenna
 - Increase the separation between the equipment and receiver
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
 - Consult the dealer or an experienced radio/TV technician for help

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-310 Compliance Statement:

This device complies with Industry Canada licence-exempt RSS-310. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Declaration of Conformity

The product is in conformity with the requirement of EU Directive 2014/53/EU

Environmental notes:

- The whole product also does not belong to household waste at the end of the product life. You can return it at collection points for the recycling of electronic and electrical instruments
- The symbol on the item, instruction manual, hangtag or packing is showing this clearly.

Materials should be recycled according to their respective markings. Recycling of old devices or other re-use of materials contained therein represents an important contribution to environmental protection. Please ask at your local community for the correct collection point.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.

You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:
Pb-Battery contains lead
Cd-Battery contains cadmium
Hg-Battery contains mercury

The packaging and instruction manual contain important information.

Please keep them for future reference.

Warning! Choking Hazard. Not suitable for children under the age of 3 years due to small parts.

We reserve the right to improve/ amend specifications and colors without notice.

Warning! The Antenna of vehicle is not to be inserted into socket outlets.

6+ 6.4V 500mAh 9V 1x9V INCLUDED

CONFORMS TO THE SAFETY REQUIREMENTS OF ASTM F963.

Batteries are for demonstration purposes only. They should be replaced upon purchase for optimal performance.

Do not mix old and new batteries. Do not mix alkaline, carbon/zinc, or rechargeable batteries.

Contents and colors may vary.

FAST LANE IS A MARK OF (ES UNA MARCA DE) TRU KIDS, INC.

© 2020 TRU KIDS INC. MADE IN CHINA (FABRICADO EN CHINA)

DISTRIBUTED IN THE UNITED STATES BY DISTRIBUTOR (LOS ESTADOS UNIDOS POR) TRU KIDS CONSUMER BRANDS, LLC

PARISPRATT, NJ 07054. www.trukids.com

www.trukidsbrands.com

BACK

Modo de juego

- Encender el vehículo.
- Usar la palanca de aceleración/derecha (Fig. 3) para mover al vehículo en un sentido u otro.
- Usar la palanca de dirección/derecha (Fig.3) para controlar los giros del vehículo hacia uno u otro lado.
- Si el vehículo no circula en línea recta, regular el ajuste de la dirección que está en el chasis del vehículo (Fig. 1).
- Jugar sobre una superficie suave para un rendimiento óptimo.
- Al terminar de jugar, apretarse de apagar (OFF) el vehículo y el transmisor.
- El alcance óptimo de control es de hasta 20 m (65ft) en exteriores.

Atención

- No conducir sobre hierba, suciedad, arena, polvo, moqueta ni agua.
- No conducir si hace mucho viento o está lloviendo.
- Evitar el choque directo con obstáculos.
- Apretar el juguete cuando no se esté usando para evitar posibles fugas de electrolito de las pilas y, por tanto, daños en el vehículo y el transmisor.
- Retirar las pilas del vehículo y del transmisor cuando no se vayan a utilizar durante mucho tiempo.
- No acercar los dedos, el pelo ni ropa holgada a las ruedas.
- Hay diversos factores que pueden afectar al alcance de funcionamiento:
 - a) Pilas con poca energía en el transmisor o vehículo.
 - b) Interferencias de otros aparatos que emitan señales de radiofrecuencia.
- Para conseguir un alcance de control óptimo, se recomienda usar el juguete en espacios abiertos.
- Se recomienda jugar sobre una superficie plana y limpia.
- Limpia el compartimento de las pilas para asegurarse de que está libre de polvo y así evitar un mal contacto de las pilas.

Advertencias

- No intentar desmontar el vehículo ni el transmisor.
- No utilizar el vehículo en una zona con otros vehículos de la misma frecuencia.
- Asegurarse de que las pilas estén colocadas con la polaridad correcta (+/-), tal como se indica dentro del compartimento correspondiente.
- Quitar todo el material de embalaje y sacar todos los accesorios antes de darle el vehículo y el transmisor al niño para que juegue.

Declaración de cumplimiento con la Comisión Federal de Comunicaciones (FCC):

Este dispositivo cumple con el apartado 15 de las normas de la FCC. Su manejo está sujeto a las dos condiciones siguientes:

- Este dispositivo no puede causar interferencias nocivas, y
- Este dispositivo debe aceptar cualquier interferencia recibida, incluyendo interferencias que puedan dañar a operaciones no deseadas. Nota: Las pruebas realizadas a este equipo ponen de manifiesto su adecuación a las limitas para dispositivos digitales de clase B, según el apartado 15 de las normas de la FCC. Estos límites tienen por objeto proporcionar una protección razonable contra interferencias perjudiciales en instalaciones residenciales. Este equipo genera, usa y puede radiar energía de radiofrecuencia y, si no se instala y se utiliza de acuerdo con las instrucciones, podría ocasionar interferencias dañinas para las comunicaciones por radio. No obstante, no se puede garantizar que no ocurran interferencias en una instalación específica. Si este equipo ocasiona interferencias perjudiciales en la recepción de radio o televisión, lo que puede comprobarse encendiéndolo y apagando el equipo, se recomienda al usuario que intente corregir las interferencias mediante una de las siguientes formas:
 - Cambiar la orientación o la posición de la antena receptora.
 - Aumentar la distancia entre el equipo y el receptor.
 - Conectar el equipo a una toma de corriente ubicada en un circuito distinto al que está conectada la unidad receptora.
 - Consultar al distribuidor o a un técnico experto en radio/TV en caso de necesitar ayuda.

Aviso: Cualquier cambio o modificación en este producto que no haya sido autorizado expresamente por la parte responsable del cumplimiento podría invalidar la autoridad del usuario para manejar el equipo.

Declaración de cumplimiento del RSS-310:

Este dispositivo de radiofrecuencia cumple todos los requisitos del estándar internacional RSS-310 de Canadá. Su manejo está sujeto a las dos condiciones siguientes:

- Este dispositivo no puede ocasionar interferencias, y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluyendo interferencias que puedan causar operaciones no deseadas.

Declaración de conformidad

El producto cumple las disposiciones de la Directiva 2014/53/EU

Notas sobre materia medioambiental:

El producto completo no se debe desechar con la basura doméstica al llegar al final de su vida útil. Puede reciclarse en los puntos de reciclado de productos e instrumentos electrónicos. El símbolo sobre el producto, manual de instrucciones, etiqueta o embalaje lo muestra de forma inequívoca. Los materiales se deberán reciclar de acuerdo a sus etiquetas respectivas. El reciclaje de dispositivos mejora su otra utilización de los materiales aquí contenidos supone una importante contribución a la protección del medio ambiente. Pregunte en su comunidad local el punto de reciclaje adecuado. Conserve esta hoja y dirección para futuras consultas ya que contienen información importante.

Deshechar pilas

Las pilas no deben tirarse junto con los residuos domésticos. Como consumidor, es su obligación legal devolver las pilas con sustancias dañinas y todas las demás pilas usadas. Puede entregar sus pilas viejas en puntos de recogida pública de su zona o allí donde venden pilas. Encontrará esta recomendación química junto a un dibujo de una papelería tachada en las pilas que contienen sustancias nocivas. Por la pila contiene plomo. Por la pila contiene cadmio. No la pila contiene mercurio.

El embalaje y el manual de instrucciones contienen información importante.

Conservarlos para futuras consultas.

Advertencia! Riesgo de asfixia. No apto para niños menores de 3 años. Evitar piezas pequeñas.

Nos reservamos el derecho a mejorar/modificar las especificaciones y colores sin previo aviso.

Advertencia! La antena del vehículo no debe introducirse en ninguna toma de corriente.

6+ 6.4V 500mAh 9V 1x9V INCLUIDAS

CUMPLE CON LA NORMATIVA DE SEGURIDAD ASTM F963.

Las pilas que se incluyen sólo son para demostración. Váyanse reemplazando por otras nuevas para funcionamiento óptimo.

No mezcle pilas nuevas con pilas usadas. No mezcle pilas alcalinas, carbon/zinc o recargables.

El contenido y los colores pueden variar.

FAST LANE IS A MARK OF (ES UNA MARCA DE) TRU KIDS, INC.

© 2020 TRU KIDS INC. MADE IN CHINA (FABRICADO EN CHINA)

DISTRIBUTED IN THE UNITED STATES BY DISTRIBUTOR (LOS ESTADOS UNIDOS POR) TRU KIDS CONSUMER BRANDS, LLC

PARISPRATT, NJ 07054. www.trukids.com

www.trukidsbrands.com