

1 YEAR LIMITED WARRANTY: We pride ourselves on the quality of our products. For complete warranty details and a list of our worldwide offices, please visit www.targus.com. Targus product warranty does not cover any device or product that is not manufactured by Targus (including, but not limited to, laptops, smartphones, devices, or any other product that may be used in connection with the Targus product). Targus is a registered trademark of Targus International LLC in the U.S. and in certain other countries. Microsoft, Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Mac is a trademark of Apple Inc., registered in the U.S. and other countries. Chromebook is a trademark of Google, Inc. All logos and registered trademarks are the property of their respective owners. ©2017 Targus, 1211 North Miller Street, Anaheim, CA 92806. All rights reserved.

GARANTIE LIMITÉE D'UN AN : Nous sommes fiers de la qualité de nos produits. Pour obtenir les détails complets de la garantie et une liste de nos bureaux dans le monde entier, veuillez naviguer vers www.targus.com. La garantie sur les produits Targus ne couvre pas tout appareil ou produit qui n'est pas fabriqué par Targus (y compris, sans s'y limiter, les ordinateurs portables, téléphones intelligents, appareils ou tout autre produit qui peut être utilisé en rapport avec le produit Targus). Les clients australiens peuvent obtenir les détails complets de la garantie en consultant la déclaration de garantie ci-jointe. Targus est une marque déposée de Targus International LLC dans les États-Unis et dans certains autres pays. Microsoft, Windows et Windows Vista sont des marques déposées ou marque de commerce de Microsoft Corporation dans les États-Unis et/ou dans autres pays. Mac est une marque de commerce d'Apple Inc., déposée dans les États-Unis et dans autres pays. Chromebook est une marque de commerce de Google, Inc. Tous les logos et les marques déposées sont la propriété de leurs propriétaires respectifs. ©2017 Targus, 1211 North Miller Street, Anaheim, CA 92806. Tous droits réservés.

GARANTÍA LIMITADA DE 1 AÑO: En nuestra compañía nos enorgullecemos de la calidad de nuestros productos. Para una información detallada de la garantía y una lista de nuestras oficinas alrededor del mundo, visite www.targus.com. La garantía de Targus no cubre ningún dispositivo o producto que no esté fabricado por Targus (incluyendo, de manera enunciativa y no limitativa, ordenadores portátiles, teléfonos inteligentes, dispositivos o cualquier otro producto que pueda usarse en conexión con un producto de Targus). Consumidores australianos: Para una información detallada de la garantía, consulte la declaración de garantía incluida con el producto. Targus es una marca comercial registrada de Targus International LLC en EE.UU. y otro número de países. Microsoft, Windows y Windows Vista son marcas comerciales registradas o marcas comerciales de Microsoft Corporation en los Estados Unidos y/u otros países. Mac es una marca comercial de Apple Inc., registrada en los Estados Unidos y otros países. Chromebook es una marca comercial de Google, Inc. Todos los logotipos y las marcas comerciales registradas son propiedad de sus respectivos dueños. ©2017 Targus, 1211 North Miller Street, Anaheim, CA 92806. Todos los derechos reservados.



FCC ID: OXM000077
IC: 3760B-00070



folding line
2 staples here (saddle stitching)


Targus®

**BLUETOOTH MOUSE
SOURIS BLUETOOTH
RATÓN BLUETOOTH**

**User Guide
Guide de l'utilisateur
Guía del usuario**
Model: AMB580

folding line
2 staples here (saddle stitching)

Installing the battery



1. Remove the battery cover from the back of the mouse.
2. Insert the supplied batteries, making sure that the positive (+) and negative (-) ends of each battery match the polarity indicators inside the battery housing.
3. Replace the battery cover into position until it "clicks" firmly into place.



WARNINGS: WHEN REPLACING THE BATTERIES, YOU MAY USE ALKALINE OR OTHER HEAVY-DUTY NIMH BATTERIES. NEVER USE AN ALKALINE WITH A NIMH BATTERY IN A DEVICE. AVOID MIXING NEW AND USED BATTERIES IN A DEVICE.

"ON/OFF" switch


Use the "ON/OFF" switch to power the mouse on or off. Turn OFF to save battery power.

Wake-up

The Bluetooth mouse will enter Sleep Mode if no use is detected after 8 mins. Press any button to awaken the mouse.

Establish Pairing

1. Turn on the mouse by sliding the power button to the ON position.
2. Switch ON the Bluetooth function of your device and turn on the Bluetooth search mode.
3. Press the Connect button on the bottom of the mouse and the red LED indicator will light up.



4. Tap "Bluetooth Mouse" in the Bluetooth search menu on your device.
5. Pairing will start automatically and LED indicator will turn off.

Low-voltage alarming function

When the battery has been used for a long time and the battery is low on power, the LED indicator light will alarm - "flicker" to remind user to change the battery.

Contents

- Bluetooth Mouse
- AA alkaline battery x 1
- User Guide

System requirements

- Windows® 10, Windows® 8.1, Windows® 8, Windows® 7
- Mac OS® X 10.6 - 10.12.3

Help with setup: mouse is not working

- Check the orientation of the batteries inside the mouse, or replace the batteries.
- Remove any metal object between the receiver and the mouse that may interfere with reception. Try using the mouse on a different surface.
- Restart the computer.
- Only one device can be actively paired at one time.
- After pairing for the first time, your device will automatically connect to the mouse the within 3-5 seconds the next time you turn the mouse on.
- In case of connection failure, delete the pairing record from your device, and try the above pairing procedures again.

Technical Support

For technical questions, please visit:

US

Canada

Australia

Internet: <http://targus.com/us/support>

Internet: <http://www.targus.com/ca/support>

Internet: <http://www.targus.com/au/support>

Email: infoaust@targus.com

Telephone: 1800-641-645

Telephone: 0800-633-222

Email: latam.soposte@targus.com

New Zealand

Latin America

Product Registration

Targus recommends that you register your Targus accessory shortly after purchasing it. Go to:

http://targus.com/us/product_registration

You will need to provide your full name, email address, country of residence and product information.

One Year Warranty

We pride ourselves on the quality of our products. For complete warranty details and a list of our worldwide offices, please visit www.targus.com. Targus product warranty does not cover any device or product that is not manufactured by Targus (including, but not limited to, laptops, smartphones, devices, or any other product that may be used in connection with the Targus product). Australian customers: For complete warranty details see warranty statement enclosed. Targus is a registered trademark of Targus International LLC in the U.S. and in certain other countries. Microsoft, Windows and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Mac is a trademark of Apple Inc., registered in the U.S. and other countries. Chromebook is a trademark of Google, Inc. All logos and registered trademarks are the property of their respective owners. ©2017 Targus, 1211 North Miller Street, Anaheim, CA 92806. All rights reserved.

Australian And New Zealand Consumers Only

Thank you for your purchase. Targus warrants to the original purchaser that its products are free from defects in materials and workmanship and, during the specified warranty period, and lasts as long as the original purchaser owns the product. The warranty period is stated on the packaging or in the documentation provided with this Targus product. Targus' Limited Product Warranty excludes damage caused by accident, neglect, abuse, misuse, improper care, normal wear and tear, ownership transfer, or alteration. The limited warranty also excludes any product that is not manufactured by Targus (including, without limitation, laptops, smartphones, devices, tablets, or any other non-Targus item) that is used in connection with the Targus product.

In the event that the Targus product has a defect in materials or workmanship Targus will, after receiving a warranty claim and inspecting the product, at its discretion, do one of the following: repair, replace, or refund with the same or a similar product (or part) of no lesser quality and ship it to the original purchaser at Targus' expense. As part of this inspection, proof of purchase will be required. There is no charge for inspection. To make a warranty claim, please contact Targus Australia or New Zealand (see details below), or return the product to the place of purchase. The original purchaser must bear the cost of the delivery to Targus.

Under Australian and/or New Zealand Consumer Laws, in addition to any warranty Targus gives, our products come with guarantees that cannot be excluded. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are entitled to have the products repaired or replaced if they fail to be of acceptable quality and the failure does not amount to a major failure.

For any warranty question, contact Targus Australia Pty. Ltd. (i) by mail at Suite 2, Level 8, 5 Rider Boulevard, Rhodes NSW 2138, by phone AUS 1800 641 645 or NZ 0800 633 222 or by Email: infoaus@targus.com. For additional information, check out our website at targus.com/au/warranty.

Regulatory Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :


- 1) l'appareil ne doit pas produire de brouillage;
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

Declaration of Conformity

Hereby, Targus declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Microsoft, Windows, and Windows Vista are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. All trademarks and registered trademarks are the property of their respective owners. All rights reserved. Features and specifications are subject to change without notice. © 2017 Targus, 1211 North Miller Street, Anaheim, CA 92806.

Installation de la pile



1. Retirer le couvercle de la pile au dos de la souris.
2. Insérer la pile fournie en vous assurant que les cotés positif (+) et négatif (-) de chaque pile respecte les indicateurs de polarité à l'intérieur du compartiment à piles.
3. Remplacer le couvercle de la pile jusqu'à ce qu'il soit fermement en place.



AVERTISSEMENTS : LORS DU REMPLACEMENT DES PILES, VOUS POUVEZ UTILISER DES PILES ALCALINES OU TOUTE AUTRE PILE NIMH PUISSANTE. NE JAMAIS COMBINER UNE PILE ALCALINE ET NIMH DANS VOTRE APPAREIL. ÉVITER DE COMBINER DE VIEILLES PILES AVEC DE NOUVELLES PILES DANS UN APPAREIL.

Interrupteur « ON/OFF »


Utiliser l'interrupteur « ON/OFF » pour activer et éteindre la souris. Éteindre pour prolonger la vie de la pile.

Réactivation

La souris Bluetooth tombera en veille après 8 minutes de non-utilisation. Appuyer sur le bouton de votre choix pour réactiver la souris. Appuyer sur le bouton de votre choix pour réactiver la souris.

Effectuer un jumelage

1. Allumer la souris en glissant l'interrupteur à la position « ON ».
2. Activer la fonction Bluetooth de votre appareil puis activer le mode de recherche Bluetooth.
3. Appuyer sur le bouton « Connect » au bas de la souris et l'indicateur DEL rouge s'allumera.



4. Cliquer sur « Souris Bluetooth » dans le menu de recherche Bluetooth de votre appareil.
5. Le jumelage démarrera automatiquement et l'indicateur DEL s'éteindra.

Fonction d'alarme de faible voltage

Lorsque la pile a été utilisée pendant longtemps et que la pile perd de sa charge, l'indicateur DEL affichera une alarme en scintillant afin de rappeler à l'utilisateur de changer la pile.

Contenu :

- Souris Bluetooth
- 1 pile alcaline AA
- Guide d'utilisation

Système requis

- Windows® 10, Windows® 8.1, Windows® 8, Windows® 7
- Mac OS® X 10.6 - 10.12.3

Aide à l'installation : la souris ne fonctionne pas

- Vérifier l'orientation des piles à l'intérieur de la souris, ou remplacer les piles.
- Retirer tout objet métallique se trouvant entre le récepteur et la souris et qui pourrait interférer avec la réception. Essayer d'utiliser la souris sur une surface différente.
- Redémarrer l'ordinateur.
- Un seul appareil à la fois peut être jumeler avec la souris.
- Après le premier jumelage, votre appareil se connectera automatiquement avec la souris à l'intérieur de 3 à 5 secondes les prochaines fois que vous allumerez la souris.
- En cas de bris de connexion, supprimer le fichier de jumelage de votre appareil puis suivre de nouveau les étapes de jumelage mentionnées ci-dessus.