

A diagram of a wristwatch with labels A through H pointing to various parts:

- A: Points to the hour hand.
- B: Points to the minute hand.
- C: Points to the second hand.
- D: Points to the watch face (dial).
- E: Points to the crown (pusher) on the case.
- F: Points to the pusher on the strap.
- G: Points to the buckle on the strap.
- H: Points to the strap.

- A. Wireless connection indicator light
- B. AUX IN indicator light
- C. Multi function button
- D. Volume + -
- E. Power ON/OFF
- F. USB Charging port
- G. Charging indicator light
- H. AUX IN

1

1. When turn on, Goosound drum will automatically connect to the last connected device if available. If not, it will enter pairing mode.
2. Open the "BT" function on your mobile phone to search for the "Goosound drum", select "Goosound drum" from the "BT" function device list to connect with the speaker, after connected, the indicator light will stop blinking.
3. Once playing music through the speaker, you could press "⏮" button to control the music pause/ play / answer the call/ hang up the call.

Note: Goosound drum will automatically turn off after 10 minutes if no device is connected. Please turn off and turn on to pair.

1. Turn on the speaker and plug audio cable into Aux in interface.
2. Connect the speaker and your PC with the included 3.5mm audio cable, press “▶||” button to pause /play music

1. Plug charging cable into the DC 5V input interface.
2. Connect the charging cable to your DC 5V adapter.

2

- | | |
|--------------------|----------------|
| Model Number | Goosound drum |
| Input | 5V/0.5A |
| Audio output | 5W |
| BT version | 4.2 |
| BT Profile | A2DP AVCRP HFP |
| Range | 10m/33ft |
| Battery capacity | 1200mAh |
| Playing time | 4-5 hours |
| Charging time | 2.5 hours |
| Frequency response | 90Hz-20KHz |
| SNR | ≥76dB |
| Sensitivity | 80db±2db |
| Size | φ73×85mm |

3

#	Part Name	Quantity
1	Goosound drum speaker	1
2	3.5mm audio cable	1
3	Micro usb cable	1
4	Tavel pouch	1
5	User manual	1

- Enable “BT” function.
- Make sure your device is within 3ft of the speaker.
- Un-pair the speaker on your device, then try to re-pair.



- Please recharge it and make sure it has enough power.
- After fully charged, please have a try to turn it on.

4

5. The “BT” indicator remains off.
 - It suggests the battery power drops quite low and retry once being recharged.
 - Turn it on again.

We offer 12 + 6 month extended warranty & 30 days money back and 24/7 friendly customer service, welcome customers to contact us at fiona@gooloo.co

5



各部の名称と働き:

- A. ワイヤレス接続インジケータランプ
- B. AUX IN インジケータランプ
- C. マルチ機能ボタン
- D. ボリューム調整ツマミ
- E. 電源スイッチ
- F. USB電源入力ポート
- G. チャージングインジケータランプ
- H. AUX IN

7

ブルーーツス対応機器とのペアリング:

- ①本機の電源をオンにし、ペアリング可能な状態にする。
- ②本機のブルーーツスインジケータは早く点滅し、ペアリング待機の状態になります。
- ③ブルーーツス対応機器のブルーーツスリストから「Goosound drum」を選び、本機とブルーーツス対応機器を接続します。ペアリングが成功すると、ピープ音が鳴りブルーーツスインジケータは点灯に変わります。
- ④ブルーーツス対応機器とペアリングされている状態で、ブルーーツスボタンをおして、ブルーーツス対応機器で再生されたオーディオが本機から聞えます。(再生/一時停止/通話/終止コントロール出来ます。)

*本機は10分間以内にペアリングされないと、切れている可能性があるから、消しあるいは再度ペアリング操作を早くしてください。

- ① 本機の電源をオンにして、外部オーディオ機器の電源を入れます。
- ② 3.5mmステレオミニプラグケーブルの一方の端を外部オーディオ機器のAUX INジャックに挿入し、もう一方の端を本機のAUX INジャックに挿入します。
- ③ 外部オーディオ機器の再生を開始すると、本機のマルチ機能ボタンを押してから、出力が本機のスピーカーから聞こえます。

本製品についてUSB充電:
本製品に付属のUSB充電ケーブルのマイクロUSBコネクターを、製品本体の受電用マイクロUSBコネクターに接続します。

8

- 仕様:

デバイスモデル:	Goosound drum
入力:	5V/0.5A
オーディオ出力:	5W
BT バージョン	4.2
BT プロフィール	A2DP AVCRP HFP
レンジ:	10m/33ft
バッテリー容量:	1200mAh
連続音楽再生:	4-5 hours
充電時間	2.5 hours
周波数帯	90Hz-20KHz
SNR	≥76dB
感度:	80db±2db
サイズ:	φ73×85mm

9

1	Goosound drum スピーカー	1
2	3.5mm オーディオケーブル	1
3	Micro usb cable ミクロ USB ケーブル	1
4	Tavel pouch 収納ケース	1
5	User manual 日本語取扱説明書	1

①電源が入らないばあいに、どうすれば良いですか？
スピーカーの電源スイッチをオンの位置までスライドさせてください。内蔵電池をチャージしてください。

②音が出ない場合に、どうすれば良いですか？
スピーカーの音量を上げてください。スピーカーをBluetoothで再生する場合は、外部入力機器を外してください。スピーカーを外部入力で再生する場合はBluetoothの接続を切ってください。Bluetooth機器の音量を上げてください。Bluetoothのペアリングを行ってください。Bluetooth接続機器が再生状態を確認してください。

③音がひずんで、途切れるばあい、どうすれば良いですか？
再生する機器の音量を下げてください。再生する機器のバスブーストなどの機能をオフにしてください。電波の届く距離は約10mです。また障害物で電波が遮られた場合は電波

10

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.