

Dear user,

Thank you very much for choosing BT026 Speaker. Please read this user manual carefully in order to operate this device in the correct manner.


I. THINGS TO REMEMBER.

- Please store and use this product at normal temperature;
- DO NOT expose this product to rain or dampness
- DO NOT toss this product and prevent it from falling and being damaged
- DO NOT disassemble, repair and modify this product
- As it is inbuilt with lithium battery, DO NOT place it in fire to avoid danger!

II. GENTLE REMINDER

1. To prolong the speaker's life span and for your wellbeing, please don't listen to music with max volume for a long time to avoid hearing damage.
2. When something is wrong with the speaker, please immediately put it off, unplug the USB, to prevent the speaker and other parts from getting damaged.

III. OVERVIEW



Function:



Power on or Power off



Handsfree icon



Bluetooth icon

AUX AUX line in

DC 5V DC 5V jack



Battery indicator icon



Bluetooth indicator icon

 AUX Aux indicator icon

 Decrease volume or select last track

 Increase volume or select next track

 Play or Pause

 Scene Lamp Switch

 Increase Lightness

 Decrease Lightness

IV. SPECIFICATIONS

Model: BT026

Bluetooth specification: Bluetooth V4.2

Transmission distance : $\leq 10M$

USB charging voltage: DC 5V/500mA

Built-in battery: Lithium battery, 4000mAh

Output power: 6W x 2

Frequency response: 90Hz-20KHz

Sensitivity: 80db $\pm$ 2db

S/N ratio: $\geq 76dB$

V. PACKING LIST

1. Speaker * 1
2. USB cable * 1
3. User manual * 1

VI. FUNCTION DESCRIPTION

BLUETOOTH OPERATION

1. Turn on the speaker. The blue indicator light will flash to detect Bluetooth enabled devices near you. The blue indicator light will go out if no Bluetooth device is detected within 5 minutes.
2. Pair the speaker with the desired Bluetooth device.
3. Play/pause as desired by pressing. 

AUX PLAYBACK OPERATION

1. Turn on the speaker.
2. Insert a 3.5mm audio cable into the aux jack on the back of the speaker, connecting to any audio device such as mobile phones or computers with the other port.
3. press  to enter mute mode and re-press  to release the sound.

LAMP LIGHT OPERATION

1. Press  to turn on the lamp light

2. Press **+** **-** to control the lightness.

CHARGING THE SPEAKER

The speaker has a built-in Lithium battery. The battery is rechargeable and provides approx 18 hours of continuous operation when fully charged.

Use the micro-USB cable to charge the speaker. The red indicator light will illuminate. The red indicator light will go off when the speaker is fully charged.

VIII. COMPATIBILITY

Device equipped with BLUETOOTH 2.1 or higher version, such as the iPad, iPhone, iPod Touch as well as a majority of "Smartphone" that support Bluetooth.

Bluetooth 2.1 including agreements as: A2DP, AVRCP, HFP.

VIII. TROUBLESHOOTING

PHENOMENO PROBLEM	TROUBLESHOOTING
Failure in connection and pairing	1. Inspect whether the speaker is in search mode or restart the machine. 2. If many Bluetooth enabled devices are switched on then it will cause difficulty in searching the device. So, please switch off other Bluetooth equipments.
The sound is less or distorted	1. Inspect the volume of the Bluetooth equipment and adjust the volume. 2. The power of battery might be insufficient. Please charge it.
Discontinuous music	See whether the effective connection distance of sound is exceeded, or, whether there is obstacle between the speaker and the Bluetooth equipment.
The indicator for Bluetooth mode is not on	1. It indicates that the power of the battery is not sufficient. Please try again after charging it. 2. Restart the machine.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.