

#70212|13|14 Brookstone Rhapsody Bluetooth Headphones

Please read the following clearly before you do the printing of all kinds of our instruction sheets.

- 1) The folded size should be 3”W x 3”H.
- 2) Please exactly follow all the trim marks and fold marks.
- 3) Please exactly follow the page in proper order. (page numbers do not need to print)
- 4) The color of this kind instruction is : 1C(Cool Gray 10C) + 1C(Cool Gray 10C)
- 5) Use 90gsm gloss art paper for bulk production.
- 6) “S” fold should be used for this item.
- 7) There are gradient colors inside this file.

Brookstone®
Rhapsody Bluetooth Headphones

FCC ID:OYCH010

User Manual

Thank you for using our company's Bluetooth Headphones. Please read this user manual carefully in order to operate this product correctly.

- NOTICE**
- Please store and use this product at a normal temperature
 - DO NOT expose this product to rain or damp areas
 - DO NOT throw or drop this product
 - DO NOT disassemble, repair or modify this product
 - This product has a lithium battery, to avoid danger DO NOT place it near or in a fire

- KIND REMINDER**
1. To prolong the headphones life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.
2. When an error occurs with the headphones, please turn off the product and restart to troubleshoot.
3. When the headphone power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruptions during use.



1. Volume Down / Previous Song
2. Next Song / Volume Up
3. Play & Pause / Call pick-up & hang-up
4. Press and hold for 3 seconds to turn the headphone ON or OFF

SPECIFICATION

Model : Brookstone Rhapsody Bluetooth Headphones
Bluetooth specification : Bluetooth V4.0
Transmission distance : 10M (It varied when the environmental factors and the connected Bluetooth devices are different)
Built-in battery : Lithium battery, 280mAh
Output power : 30mW
Frequency response : 20Hz - 20KHz
Sensitivity : 105db (AT 1KHz + 3db)

BLUETOOTH OPERATION

1. Press and hold power button to turn on the headphones. The blue indicator light will flash to detect Bluetooth enabled devices near you. The blue indicator light will go out if no Bluetooth device is detected within 5 minutes.
2. Pair the headphone with the desired Bluetooth device.
3. Play / Pause as desired by pressing .
4. To answer an incoming phone call while using the headphones, press the button once. To end the phone call, re-press the . Press twice to call the last number dialed.

AUX PLAYBACK OPERATION

1. Turn on the headphone.
2. Insert a 3.5mm audio cable into the AUX jack on the back of the headphone. Connect the 3.5mm cable to any audio device with a port.
3. Press the button to play or pause music.

CHARGING THE HEADPHONES

1. The headphone has a built-in Lithium battery. The battery is rechargeable and provides approximately 5 hours of continuous use at 80% volume when fully charged.
2. Use the micro-USB cable to charge the headphone. The red indicator light will illuminate when the battery is low. The red indicator light will go out when the headphone is fully charged.

COMPATIBILITY

Devices equipped with Bluetooth 3.0 or higher (for details please refer to the user manual of that device). Bluetooth 3.0 including agreements as : A2DP, AVRCP, HFP.

PACKING LIST

- Headphone x 1
- AUX cable x 1
- USB cable x 1
- User manual x 1

PROBLEM	TROUBLESHOOTING
Failure to connect or pair the headphones to an audio device	• Confirm the device you wish to pair with the headphone has Bluetooth capabilities. • Check battery life, headphones may need to be charged. • Inspect whether the headphone is in the status of searching for Bluetooth device. • There may be too many Bluetooth enabled devices in the area, please turn off Bluetooth function on devices you do not want to pair with the headphones.
The sound is too low or distorted	• Inspect the volume of the Bluetooth equipment and adjust the volume. • The battery life is low, please charge the headphones.
Discontinuous music	• Move the paired Bluetooth device closer to the headphones. • Make sure there are no obstacles between the Bluetooth device and the headphones.
The indicator light for Bluetooth mode is not on	• The battery life is too low, please charge the headphones and try again. • Restart the headphones by powering off and turning back on.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation.**