



Battery Installation

Vehicle Battery Installation





- Cautions:
- Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are to be removed from the toy before being charged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Different types of batteries or new and used batteries are not to be mixed.
 - Only batteries of the same or equivalent type as recommended are to be used.
 - Batteries are to be inserted with correct polarity.
 - Exhausted batteries are to be removed from the toy.
 - The supply terminals are not to be short-circuited.

- Note:
- Parental guidance is recommended when installing or replacing batteries.
 - New and alkaline batteries are recommended to use in this toy to obtain best and maximum performance.
 - You are advised to replace with new batteries as soon as the function becomes impaired.
 - Interference will cause loss of control or uncontrolled running of vehicle if used in vicinity of cordless telephones, baby monitors, electronic devices or other radio controlled devices.
 - To race 2 vehicles at the same time, each must have a separate frequency. One with 27MHz, and the other with 49MHz, if both have the same frequency, their signals will interfere with each other.
 - Users should keep and retain this information for future reference.
 - Users should keep strict accordance with the manufacturer's instructions while operating the product.

- Safety Precautions:
- Parents, this toy is recommended for children 5 years and older. To ensure that your child's play is both safe and fun, please review the operating instructions with your children. If toy in the presence of children under 5 years of age, adult supervision is recommended.
 - DO NOT pick up moving vehicle
 - Keep hands, hair and loose clothing away from the tires and the wheel hubs when power switch is turned ON.
 - Remove battery pack and transmitter battery when not in use.
 - DO NOT operate your vehicle on street. Avoid hitting people, pets or home furnishings.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- Care and Maintenance:
- Always remove batteries from the toy when it is not being used for a long period of time.
 - Wipe the toy gently with a clean damp cloth.
 - Keep the toy away from direct sunlight and/or direct heat.
 - Do not submerge the toy into water that can damage the electronic assemblies.

Transmitter Battery Installation



TURBO 2 in 1 RC-PRO

Radio Control / Program Control
Radio Control + Program Control


Radio Control

- Wireless direct driving fun
- R/C control interrupts program actions

Program Control

- 32 distinct program actions
- Endless programming possibilities

(Please Read Thoroughly Before Operating Your Vehicle)



Parts Description

