

---

**Transmitter**

- 1) Open case to reveal 10 position DIP switch and Reed switch terminal
- 2) Set Code (1-8)
  - a) Set the first eight switch positions on S1
    - i) Code must match the code set on the receiver S1
- 3) Select door number transmitter is mounted on
  - a) Set S1-9 and S1-10 using table 2.

| S1-9 | S1-10 | Door Number |
|------|-------|-------------|
| On   | On    | 3           |
| Off  | On    | 2           |
| On   | Off   | 1           |
|      |       |             |

Table 2.

- 4) Mount transmitter in safe location
- 5) Press and release Test Button on transmitter
  - a) This will sync the transmitter and receiver

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.