

4.19. ADT Live Light Outdoor Sign (ADTPLUS-YS-R0)

Your ADT Live Light Outdoor Sign illuminates whenever an alarm is set off. When a sensor is tripped, the Live Light Outdoor Sign will illuminate along with sounding the siren in your ADT Base. This will alert emergency responders and help guide them to your home, especially after dark. Place this sign in a location where it can be seen by emergency responders and neighbors. The ADT Live Light can be mounted on a wall or on the included ground stake.

The Live Light Outdoor Sign illuminates during an alarm event. The following table compares the audible notifications heard from the ADT Base versus what is heard from the ADT Indoor Siren for each type of action.

ACTION	ADT Base	ADT Live Light
Burglary Alarm	Piezo – Burglary Sound	Illuminated white/blue
Panic - Police	Piezo - Burglary Sound	Illuminated white/blue
V4 Smoke	Piezo – 3 Beep Cadence	Illuminated white/blue
V5 Smoke	Piezo – 3 Beep Cadence	Illuminated white/blue
Panic – Fire	Piezo – 3 Beep Cadence	Illuminated white/blue
CO Alarm	Piezo – 4 Beep Cadence	Illuminated white/blue
Panic – Medical	Piezo – Medical Sound	Illuminated white/blue

Setting up your ADT Indoor Siren

1. Open the ADT App and log in to an existing account.
2. Select **Menu > Devices > (+) Add Device > ADT Device > Security Devices > Live Light**.
3. Follow the in-app steps to power on the sign and mount it properly.

Open the battery cover located on the back of the device by removing 4 Philipps head screws.

Note: Do not attempt to pry off the bottom cover of the ADT Live Light as this will result in damage to the device.

The rear panel of the ADT Live Light can be removed by placing the unit face down on a clean surface and removing the 4 Philipps screws, being careful not to lose them. Once it is unfastened, the rear panel can be lifted off to reveal the battery compartment. Remove the plastic battery tab to power on the unit. When replacing dead batteries, follow the same steps, taking care of the correct polarity when inserting the batteries. Reposition the rear cover by aligning the cover with the screw holes on the rear of the ADT Live Light. Once the cover is aligned, gently insert the 4 screws and tighten in a clockwise direction until seated.

The LED light on the front of the device will start blinking blue when it is ready to pair with the ADT Base.

Mounting tips:

- This device can be mounted to a wall or in the ground using the provided stake.
- For a wall mount, detach the mounting bracket from the bottom of the sign. Use the provided screws to mount the bracket to the wall. Clip the sign to the bracket.
Note: You may need a drill and Phillips screwdriver or different screws/anchors depending on your home's construction.
- For ground mounting, assemble the 3-part post by pressing the sections together. Place in the desired location and firmly press the post into the ground using the footstep. Ensure that the post is straight and solidly anchored. Carefully slide the sign body onto the post.

Operating specifications

Temperature: -4° to 122°F (-20° to 50°C)

Outdoor use: IP65 rated; designed to withstand rain, snow and extreme temperatures

Test Live Light Function

You can test the ADT Live Light by using the ADT+ app. Open the Devices tab and select your Live Light. Another tab will open showing the status of the Live Light. You can turn the Live Light on and off from this screen. **Note:** Leaving the Live Light on for extended periods will drain the batteries.

Resetting your ADT Live Light.

- Remove the sign's battery cover. (See note above regarding back cover removal).
- Press and hold the reset button for 5-10 seconds.
- Release the reset button.
- Once the light on the sign starts blinking, place the siren's battery cover back on.

Note: If the sign is reset while already paired to your account, it will be removed and will need to be set up as a new device.

Note: Replace with 3 lithium AA batteries only.