

USER MANUL

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1. Insert the PS/2 port into the computer and restart it.
2. Insert the batteries into the receiver (2 AAA size batteries).
3. Make the distance between the mouse and keyboard within 50 cm, press the ID switch on the bottom of the mouse. Within 10 sec, press the ID switch on the bottom of the keyboard, then you should see a light flashing when mouse is moved. It means that the mouse and receiver are communicating successfully. If you don't see a light flashing or if the mouse is not responding, you may repeat 1&3.
4. You must follow the above instruction so that you can operate it correctly. If you need to change the batteries, you need to repeat 1~3. If you have some question please contact us
Tel: 0769-5338571
5. Frequency : 27MHz.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.