

Security Code Information for Model 3080

Digital Security System

The GH3080 Cordless Telephone is equipped with the 65536 codes in digital security coding system randomly to protect your base unit from being accessed by other cordless telephone.

The code allows your base and handset to recognize each other so that other cordless phones will not make calls on your line.

This code is accessed by handset registration to base unit.

HANDSET REGISTRATION

1. Press and hold the base CONFERENCE button about 10 sec. and then the base LCD shown "WAIT FOR REGISTOR".
2. Press and hold the handset CONFERENCE button about 10 sec. too, and then handset LCD shown "REGISTOR NOW". If successful in registration. The handset LCD shown "REGISTOR OK" and sound short beep tone.