

1. SPECIFICATION:

Model Number: EJT-4F

Encoder: 4 Channel

Frequency: 72.79MHz

Modulation: FM


Low Battery Indicator: LED blinking under 8 Volt.

Current Drain: 100mA

Power Source: 1.2V NiCd Cell X 8
or 1.5V Dry Cell X 8

Control Range: 1.5ms +/- 0.5ms

2. FRONT PANEL LAYOUT



3. PRECAUTIONS

- Do not fly simultaneously on the same frequency.
- Extended the antenna to its full length, always do the range check before flying.
- Always turn on the transmitter first, then the receiver. Turn the receiver off, then the transmitter.

This is very important to follow the procedure as above, otherwise, unexpected injury may occur to you or the other people around you.