



APPENDIX I SETUP PHOTOS

RADIATED EMISSION MEASUREMENT SETUP

Below 1GHz

Test Mode: Normal Operation mode





Test Mode: Charge mode





RADIATED RF MEASUREMENT SETUP





RF CONDUCTED SETUP



CONDUCTED EMISSION MEASUREMENT SETUP

Test Mode: Charge mode

