



Searching by Phone Number

1. Press , (Phonebook), (Search), (Number).

2. Enter all or part of the number you remember and press .

3. The phone displays the memory location and names which contain your entry.

NOTE: "NO NUMBER MATCHES" appears when there is no number matching your entry.

4. Press (or ,) to search for the name you're looking for and press to display the number.

NOTE: "ENTER LOCK CODE" appears when you try to access secretly saved number. Enter the lock code and press .

5. Press to dial the number displayed.



Searching by Memory Location

1. Press , (Phonebook), (Search), (Memory).

2. Enter the two-digit memory location. The phone displays the information of the memory location.

NOTE: "EMPTY LOCATION!" displays when you enter location number that is empty.

3. Press to display the number.

NOTE: "ENTER LOCK CODE" appears when you try to access secretly saved number. Enter the lock code and press .

4. Press to dial the number displayed.



E RASING AN ENTRY IN PHONEBOOK








To Erase a Specific Number

1. Press , (Phonebook) and (Erase).
2. Press one of search options: (Name), (Number) or (Memory).
3. Enter name, address, or phone number according to search option.
4. Select an item to erase by pressing (or ,) and pressing .

NOTE: "ENTER LOCK CODE" appears when you try to access a secretly saved number. Enter the lock code and press .

5. Press again to erase.
6. Press again to confirm.
To cancel, press .




E RASING ALL ENTRIES IN PHONEBOOK



To Erase All Numbers in Phonebook

1. Press , (Security)
 2. Enter lock code.
- NOTE:** Default Lock code is last 4 digits of your phone number. To change lock code, see page 33.
3. Press (Erase Names).
 4. Press to confirm.





ONE-TOUCH DIALING

Memory locations 01 ~ 09 are special one-touch dialing locations. You can dial the numbers stored in 01~09 by pressing just one key.

1. Pick up the handset or press .
2. Press and hold the number of the location (1~9) containing the number to be called for a moment.
3. The name and the phone number displays and dials automatically.

NOTE: Location 1 may be preprogrammed as emergency number or voice mail. Please check with your service provider.




TWO-TOUCH DIALING

Memory locations 10 ~ 99 are two-touch dialing locations. You can dial the numbers stored in 10~99 by pressing the first digit and pressing and holding the second digit.

1. Pick up the handset or press .
2. Briefly press the first digit of the memory location number, then press the second digit and hold it down for a moment.

Example) To dial location 23, briefly press the 2, then press 3 and hold for a moment.

3. The phone number stored displays and dials automatically.



NOTE1: When you try one-touch or two-touch dialing for the number secretly saved, the phone will prompt for Lock code entry. Enter the lock code to make a call.

NOTE2: "EMPTY LOCATION" displays when you try one-touch or two-touch dialing with empty location number.



Useful Features

Call History
Displaying Your Phone Number
Mute
Selecting Time Mode
Setting the Alarm
Checking and Clearing Call Times
Setting Warning Alerts

C ALL HISTORY

Your phone stores the last 30 outgoing calls, incoming, and missed calls combined (only when Caller ID function is activated).

You can display and redial these numbers.



Redialing Outgoing Calls

1. Press , (Call History), (Outgoing).




NOTE: If there's no outgoing call history, "OUTGOING CALL MEMORY EMPTY!" displays.

2. Press or , to select number to redial.

3. Press to redial the number.

NOTE1: Press to see time and date of the call made. Then press to redial the number or press again to save the number in memory.

NOTE2: To redial the last number called, just pick up the handset or press and .



Returning Incoming Calls

1. Press , (Call History), (Incoming).


NOTE: If there's no incoming call record, "INCOMING CALL MEMORY EMPTY!" displays.

2. Press or , to select number to redial.

3. Press to call back the number.

NOTE1: Press to see time and date of the call arrival. Then press to redial the number or press again to save the number in memory.

NOTE2: Incoming history is available only when caller ID is activated.



Redialing missed Calls

To display a list of missed received calls.

1. Press , (Call History), (Missed).

NOTE: If there's no missed call record, "MISSED CALL MEMORY EMPTY!" displays.

2. Press or , to select number to redial.

3. Press to call back the number.

NOTE1: Press to see time and date of the call arrival. Then press to redial the number or press again to save the number in memory.



NOTE2: Missed history is available only when caller ID is activated.

**Erasing Call History**

1. Press , (Security)
2. Enter lock code.

NOTE: Default Lock code is last 4 digits of your phone number. To change lock code, see page 33.

3. Press (Erase Logs).
4. Press to confirm.

**Call Timer Display**

1. Toggle Call Timer Display
2. Press . Press (Configuration).
3. Press (Call Timer).
4. Scroll to select ON or OFF.
5. Press to confirm.

D ISPLAYING YOUR PHONE NUMBER

Displaying Your Phone Number


1. Press , (Configuration).
2. Press (My Phone Number).



M UTE

This feature lets you mute the microphone, so that the other party cannot hear your voice or the sound of your surroundings. This function is available only during conversation.


1. Press , (Mute) during conversation.
The message 'MUTE' blinks to indicate the function is working. The other party can no longer hear you, but you can hear them.
2. Press , again to resume the conversation.



S ELECTING TIME MODE

1. Press ,  (Time),  (Time Mode).
2. Select the time display mode by pressing
 (or , ).
- AM/PM: Display 0~12 hours with A or P indicator
24 Hour: Display 00~24 hours


3. Press  to save the change.



SETTING THE ALARM

You can set the alarm sound daily or one time only.

1. Press ,  (Time),  (Alarm).
2. Select "SET" by pressing  (or , ) and press .
3. Enter alarm time and press .
4. Select alarm mode by pressing  (or , ) and press .
Daily: Alarm sounds daily.
One time: Alarm sounds once.
5. Enter the duration of the alarm by pressing  (or , ) and press .
A bell icon (🔔) appears in icon line.
At alarm time, the icon and "ALARM TIME" message blinks and alarm goes off.
Press any key to stop the alarm.



Canceling the Alarm Time


1. Press ,  (Time),  (Alarm).
2. Select "RELEASE" by pressing  (or , ) and press  to cancel the alarm.

CHECKING AND CLEARING CALL TIMES




Checking the Last Call Time

1. Press , (Time), (Last Call).
2. Press to clear the display.




Checking Accumulated Incoming Call Time

1. Press , (Time), (Total Time), (Incoming).
2. Press to clear the display.




Checking Accumulated Outgoing Call Air Time

1. Press , (Time), (Total Time), (Outgoing).
2. Press to clear the display.



Reset Accumulated Call Time

1. Press , (Time), (Clear Call Time).
2. Press .



SETTING WARNING ALERTS

You can set your phone to sound warning beeps that indicate:

- each minute you are on a phone call
- when you are out of the service area



Setting/Releasing 1 Minute Alert

1. Press , (Sound), (1 Min Alert).
2. Select ON or OFF by pressing (or ,).
3. Press .

NOTE: When 1 minute alert is set, the phone gives alert sound each minute while you are on a phone call.



Setting/Releasing Service Alert

1. Press , (Sound), (Service Alert).
2. Select ON or OFF by pressing (or ,).
3. Press .

NOTE: When service alert is set, the phone gives alert sound when the phone is acquiring or loses the service signal.



Setting/Releasing Connection Alert

1. Press , (Sound), (Connect Alert).
2. Select ON or OFF by pressing (or ,).
3. Press .

NOTE: When connection alert is set, the phone gives alert sound when the call has been connected to the number dialed.



Setting/Releasing Voice Privacy Alert

1. Press , (Sound), (Voice Privacy Alert).
2. Select ON or OFF by pressing (or ,).
3. Press .

NOTE: When voice privacy alert is set, the phone gives alert sound when the voice privacy is on.

