




International Electronics Inc.
NetLock Label (Item 5) Placement
Label is located under the battery cover above the battery holder
9/22/05 Rev.1