

Instant Wireless™ Series

Network CardBus Card



Use this Guide to install:

WPC12

User Guide

 **LINKSYS®**

COPYRIGHT & TRADEMARKS

Copyright © 2002 Linksys, All Rights Reserved. Instant Wireless™ is a registered trademark of Linksys. Microsoft, Windows, and the Windows logo are registered trademarks of Microsoft Corporation. All other trademarks and brand names are the property of their respective proprietors.

LIMITED WARRANTY

Linksys guarantees that every Instant Wireless™ Network PC Card ver. 3.0 is free from physical defects in material and workmanship for one year from the date of purchase, when used within the limits set forth in the Specifications chapter of this User Guide. If these products prove defective during this warranty period, call Linksys Technical Support in order to obtain a Return Authorization Number. BE SURE TO HAVE YOUR PROOF OF PURCHASE AND A BARCODE FROM THE PRODUCT'S PACKAGING ON HAND WHEN CALLING. RETURN REQUESTS CANNOT BE PROCESSED WITHOUT PROOF OF PURCHASE. When returning a product, mark the Return Authorization Number clearly on the outside of the package and include your original proof of purchase. All customers located outside of the United States of America and Canada shall be held responsible for shipping and handling charges.

IN NO EVENT SHALL LINKSYS' LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, ITS ACCOMPANYING SOFTWARE, OR ITS DOCUMENTATION. LINKSYS DOES NOT OFFER REFUNDS FOR ANY PRODUCT. Linksys makes no warranty or representation, expressed, implied, or statutory, with respect to its products or the contents or use of this documentation and all accompanying software, and specifically disclaims its quality, performance, merchantability, or fitness for any particular purpose. Linksys reserves the right to revise or update its products, software, or documentation without obligation to notify any individual or entity. Please direct all inquiries to:

Linksys P.O. Box 18558, Irvine, CA 92623.

FCC STATEMENT

This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment or devices
- Connect the equipment to an outlet other than the receiver's
- Consult a dealer or an experienced radio/TV technician for assistance

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter

Table of Contents

Chapter 1: Introduction	1	Chapter 9: Advanced Properties	41
The Instant Wireless™ Network PC Card ver. 3.0	1	Advanced Properties for Windows 95, 98, ME, and 2000	41
Features	1	Advanced Properties for Windows NT	49
Package Contents	2		
System Requirements	2	Chapter 10: Troubleshooting	56
		Common Problems and Solutions	56
Chapter 2: Planning Your Wireless Network	3	Frequently Asked Questions	57
Network Topology	3		
Roaming	3	Chapter 11: Glossary	61
Chapter 3: Installing the Drivers and Configuration Utility for Windows 95, 98, ME and 2000	4	Chapter 12: Specifications	68
Before You Start	4	Environmental	68
Running the Auto Driver Installation	4		
Ad-Hoc Versus Infrastructure Mode	8	Chapter 13: Warranty Information	69
Infrastructure Mode	9		
Ad-Hoc Mode	11	Chapter 14: Contact Information	70
Chapter 4: Installing the Drivers and Configuration Utility for Windows XP	14		
Chapter 5: Installing the Network PC Card	16		
Chapter 6: Installing the Drivers and Configuration Utility for Windows NT	17		
Overview	17		
Installing the Network PC Card in Your Notebook PC	17		
Installing the Drivers for Windows NT	18		
Installing the Configuration Utility for Windows NT	30		
Chapter 7: Configuration Utility	30		
Using the Configuration Utility	30		
Chapter 8: Installing Network Protocols	39		