

Warning:

It is possible that the receiver may be too far from the wireless mouse or too near a large metal (or computer monitor CPU object) may be interfering with the receiver's radio reception (LED sparkling), please try changing the position of the receiver.



WIRELESS


THE HIGH-PRECISION RADIO FREQUENCY SCROLL MOUSE

美科技股份有限公司
90.5.03
開發部承認章




User's Manual

General Function Setting:



- * Press middle or right button to set the functions below.
- * Press middle or right button once to practice the functions.
- * To stop the function just press middle button.

Choose Wheel Mode/Parameters:



- ☐ Enable Background wheel
- ☐ Set window Active
- ☐ Wheel Page Scroll
- ☐ Wheel Scroll lines

Wheel Function Setting:

Choose wheel 4D and press the task button to view the window below.



Choose wheel To Scroll and press the task button to set the speed.

