

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should




Contents

Language	Page
English	06-10
Spanish	11-15
French	16-20
Italian	21-25
Arabic	26-30

Package Contents / Inhaltsgüter / Contenu du paquet / Contenuto della confezione / Contenido del Embalaje / Inhoud verpakking

- Bluetooth Stereo Speaker
- Bluetooth Stereo Speaker
- Bluetooth Stereo Speaker
- Bluetooth Stereo Speaker
- Bluetooth Stereo Speaker




- 1. Power button
- 2. Volume up button
- 3. Volume down button
- 4. Bluetooth button
- 5. USB port
- 6. AUX port
- 7. Microphone
- 8. Headset button
- 9. Headset button
- 10. Headset button




- 1. Power button
- 2. Volume up button
- 3. Volume down button

1. Bluetooth connection plug part of this plug, plug into the bottom of the speaker.



Charging


The red LED will be on when the speaker is charging. The blue LED will be on when the speaker is fully charged. The red LED will blink when the battery is low, please charge it in time.



Power button

Turn on or off
To turn on the speaker, press the power button shortly. To turn off the speaker, press the power button slowly.


Note:
The speaker will automatically turn off after 60 minutes without audio signal input. The status light will turn on automatically when you approach the speaker in dark mode.



OPTION 1 BLUETOOTH CONNECTION

1. Activate the Bluetooth function on your device, and search for the speaker.
2. Select "Rapoo A800".
3. The blue LED will be on when the Bluetooth connection is successful.


Note:
1. The Bluetooth speaker will show the connection status. If you do not have a pair key, it will show "Bluetooth" and "A800" on the speaker's display.
2. The Bluetooth speaker will show "A800" on the speaker's display.
3. The Bluetooth speaker will show "A800" on the speaker's display.



OPTION 2 NFC CONNECTION (RX)


Activate the NFC settings on your smartphone or other device, place your device's NFC zone on the speaker's NFC zone (within 1cm), the speaker will automatically connect to your device.

* This feature is not suitable for NFC-enabled devices.




OPTION 3 WIRED CONNECTION

Use the audio cable to connect the speaker to a device. If the speaker is already connected to a device via Bluetooth, please turn off the Bluetooth connection first.




1. Connect the USB cable to the speaker's USB port.
2. Connect the USB cable to a power source.
3. The red LED will be on when the speaker is charging. The blue LED will be on when the speaker is fully charged. The red LED will blink when the battery is low, please charge it in time.




Turn on or off
To turn on the speaker, press the power button shortly. To turn off the speaker, press the power button slowly.

Note:
The speaker will automatically turn off after 60 minutes without audio signal input. The status light will turn on automatically when you approach the speaker in dark mode.




1. Activate the Bluetooth function on your device, and search for the speaker.
2. Select "Rapoo A800".
3. The blue LED will be on when the Bluetooth connection is successful.

Note:
1. The Bluetooth speaker will show the connection status. If you do not have a pair key, it will show "Bluetooth" and "A800" on the speaker's display.
2. The Bluetooth speaker will show "A800" on the speaker's display.
3. The Bluetooth speaker will show "A800" on the speaker's display.




Activate the NFC settings on your smartphone or other device, place your device's NFC zone on the speaker's NFC zone (within 1cm), the speaker will automatically connect to your device.

* This feature is not suitable for NFC-enabled devices.



Use the audio cable to connect the speaker to a device. If the speaker is already connected to a device via Bluetooth, please turn off the Bluetooth connection first.




1. Connect the USB cable to the speaker's USB port.
2. Connect the USB cable to a power source.
3. The red LED will be on when the speaker is charging. The blue LED will be on when the speaker is fully charged. The red LED will blink when the battery is low, please charge it in time.




Turn on or off
To turn on the speaker, press the power button shortly. To turn off the speaker, press the power button slowly.

Note:
The speaker will automatically turn off after 60 minutes without audio signal input. The status light will turn on automatically when you approach the speaker in dark mode.




1. Activate the Bluetooth function on your device, and search for the speaker.
2. Select "Rapoo A800".
3. The blue LED will be on when the Bluetooth connection is successful.

Note:
1. The Bluetooth speaker will show the connection status. If you do not have a pair key, it will show "Bluetooth" and "A800" on the speaker's display.
2. The Bluetooth speaker will show "A800" on the speaker's display.
3. The Bluetooth speaker will show "A800" on the speaker's display.



Activate the NFC settings on your smartphone or other device, place your device's NFC zone on the speaker's NFC zone (within 1cm), the speaker will automatically connect to your device.

* This feature is not suitable for NFC-enabled devices.



Use the audio cable to connect the speaker to a device. If the speaker is already connected to a device via Bluetooth, please turn off the Bluetooth connection first.