

Figure 3
Removed the Bottom Cover (Internal View)




Figure 4
Removed the Top Cover (Internal View)




Figure 5
Internal View (Removed CD-Tray)




Figure 6
Internal View (Removed the Main Board & Control Board)




Figure 7
Internal View (Main Board/Front Side)



Figure 8
Internal View (Main Board/Back Side)



Figure 9
Internal View (Control Board/Front Side)




Figure 10
Internal View (Control Board/Back Side)




Figure 11
Internal View (Pickup/Front View)




Figure 12
Internal View (Pickup/Back View)




Figure 13
Internal View (Motor)

