


461

Mkr 1.944GHz 59.59dBuV Tek

Ref Lvl 77.0dBuV 10dB/ Atten 0dB



1.000GHz to 5.000GHz
ResBW 1MHz VidBW 7MHz SWP 40ms


LEVEL SPAN Start 1.000GHz

KN0B 2 KN0B 1 KEYPAD Tektronix 2784

462

Mkr 5.715GHz 73.19dBuV Tek

Ref Lvl 77.0dBuV 10dB/ Atten 0dB



5.000GHz to 10.000GHz

ResBW 1MHz VidBW 7MHz SWP 71ms


LEVEL SPAN Strt 5.000GHz

KN0B 2 KN0B 1 KEYPAD Tektronix 2784

463

Mkr 12.000GHz 27.89dBuV Tek

Ref Lvl 77.0dBuV 10dB/ Atten 0dB




10.000GHz to 14.000GHz
ResBW 1MHz VidBW 7MHz SWP 71ms

LEVEL SPAN Stop 14.000GHz

4164

Mkr 16.000GHz 33.49dBu Tek

Ref Lvl 77.0dBu 10dB/ Atten 0dB



14.000GHz to 18.000GHz

ResBW 1MHz VidBW 7MHz SWP 40ms


LEVEL SPAN Stop 18.000GHz

Knob 2 Knob 1 Keypad Tektronix 2784

465

Mkr 20.500GHz 31.89dBu Tek

Ref Lvl 77.0dBu 10dB/ Atten 0dB



18.000GHz to 23.000GHz


ResBW 1MHz VidBW 7MHz SWP 76ms

LEVEL SPAN Stop 23.000GHz

466

Mkr 25.500GHz 37.49dBu Tek

Ref Lvl 77.0dBu 10dB/ Atten 0dB



23.000GHz

to

28.000GHz

ResBW 1MHz

VideoBW 7MHz

SWP 50ms

LEVEL

SPAN

Stop

28.000GHz

Knob 2

Knob 1

Keypad

Tektronix

2784

467

Mkr 31.000GHz


47.09dBuV

Tek

Ref Lvl 77.0dBuV

10dB/

Atten 0dB



28.000GHz

to

34.000GHz

ResBW 1MHz

VIDBW 7MHz

SWP 74ms

LEVEL

SPAN

Stop 34.000GHz

Knob 2

Knob 1


KEYPAD

Tektronix

2784

37.000GHz 49.19dBu Tek

af Lvl 77.0dBu 10dB/ Atten 0dB



34.000GHz to 40.000GHz
asBW 1MHz VidBW 7MHz SWP 99ms

LEVEL SPAN Stop 40.000GHz