





V20S


Quick Starter Guide



1. BEFORE POWERING ON, CHARGE FOR 24 HOURS




2. INSERT SIM CARD



3. FM RADIC

4. AUDIO PLAYER


1. Insert the micro SD card



2. Connect the phone with the computer via USB.



5. 3D stereo sound



FIRST OF ALL, ENABLE THE FUNCTION
Menu → Settings → SOS → Settings → Status → ON
THEN, CONFIGURE SOS NUMBERS

To set your own emergency numbers, go to Settings->SOS settings -SOS numbers. To perform the "SOS" call, long press SOS key, this will call to the first contact in the list of your emergency numbers and will send a SMS teach number in the list. If the 1st number phone in the list of emergency numbers doesn't answer the emergency call, it call automatically to next number phone in the list, so on. Emergency mode: selects the On/Off feature and will turn it on or off.
Emergency Message: editable text saved.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

- interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Before a new device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC. Tests for each device are performed in positions and locations as required by the FCC.

For Head, this device has been tested and meets the FCC RF exposure guidelines.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that Contains no metal and that positions the device a minimum of 5mm from the body.

Non - compliance with the above restrictions may result in violation of RF exposure guidelines.