

單張式英文版
60磅雙交紙，W445.5*H105mm雙面印刷再彈簧折

正面

onn.

Ergonomic Wireless Mouse
With Bluetooth® Wireless Technology

Model: 100027829

PRODUCT GUIDE

January 10, 2022_V1

Walmart Inc.,
Bentonville, AR 72716

**Federal Communication Commission
Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement:
The product complies with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Before Use

Notes:
All parts have to be unpacked and the packaging material has to be removed completely. Before use, verify the package contents are complete and undamaged.

BATTERY WARNING STATEMENT

Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc.) batteries.

System Requirements

- Windows® 7/8/10/11 or later, macOS® 10.5 or later, Android™ Chrome OS™
- Available USB port or Bluetooth® on your laptop or computer

What's in the Box

- 1 Wireless Mouse
- 1 USB nano receiver
- 1 AA battery

Specification

- 6 Clickable buttons
- 5 adjustable sensitivity levels: 600/1000/1600/2400/3600
- Connect to up to 3 devices simultaneously with Bluetooth® wireless technology or a USB nano receiver (stores in battery compartment when not in use)
- USB plug and play
- Scroll wheel
- On/off switch
- Easy-switch for changing connection: 2.4Ghz/Bluetooth® 1/Bluetooth® 2
- Windows, MacOS, ChromeOS, Android, iOS compatible
- 4.5 in L x 3 in W x 1.65 in H (11.4 cm x 7.6 cm x 4.2 cm)

Features

Forward
Press this button to view the next page in your Internet browser.

Backward
Press this button to view the previous page in your Internet browser.

DPI Switch Key
a) 5 adjustable DPI setting
The number of blinks indicates the DPI setting in use

DPI	# of Blinks
600 dpi	1
1000 dpi	2
1600 dpi	3
2400 dpi	4
3600 dpi	5

b) Default is 1600 DPI

Switch Connection Channel

This mouse can connect up to 3 different devices.
Use "Easy-switch" to change connection channels between USB nano receiver and 2 other Bluetooth channels.

Switch between different devices
For example, you can set USB nano receiver (1) on laptop A Bluetooth (1) on desktop B Bluetooth (2) on tablet C, then use "Easy-switch" to switch connection between these 3 computers.

Connect button
Press and hold this button to set the mouse in Bluetooth pairing mode or to reconnect to a paired device.

Installing Battery
Insert the battery with the correct position according to the instructions labeled on the mouse.

Need help?
We're here for you every day from 7 a.m. – 9 p.m. CST.
Give us a call at 1-888-516-2630

We'd love to hear from you.
Scan with your smartphone camera and let us know what you think.

100027829

onn.

反面

Connection Setup

Connect via USB nano receiver
This is plug and play with USB nano receiver. Make sure to turn on power and set connection channel to USB nano receiver (1). Plug USB receiver into an available USB A port on your computer and start surfing onn.

Connect via Bluetooth in Windows
Turn on the mouse and setting it on either Bluetooth (1) or Bluetooth (2). Click on "Start" (bottom left corner on your screen) Go to Settings
-> Device -> Bluetooth & other devices -> Turn on Bluetooth
-> Add Bluetooth or other device -> Add a device (Bluetooth)

Press and HOLD "Connect" button to set mouse in pairing mode (LED will start flashing). Click on "onn.EMOUSE or BT5.1 Mouse" in the list on your computer to setup pairing. LED will stop flashing and light up for 3 seconds when complete.

START

设置

Set all your mail in one place.

Mail

Microsoft Edge

Photos

Help with Setup

USB nano receiver
Mouse is not working?
1. Is the mouse powered on? Make sure channel is set to (1).
2. Is the nano receiver securely plugged into a USB port? Try changing USB ports.
3. If the nano receiver is plugged into a USB hub, try plugging it directly into a USB port on your computer.
4. Check the orientation of the battery inside the mouse.
5. Try a different surface. Remove metallic objects between the mouse and the nano receiver.

If it is still not working, try steps below to re-pair mouse and receiver.
A. Re-plug receiver into USB port on computer, make sure channel is set to (1).
B. Press the connect button on mouse (keep mouse close to receiver).
C. If it does not work after 10 seconds, repeat steps A and B.

Bluetooth®
Mouse is not working?
1. Is the mouse powered on? Make sure channel is set to (1 or 2).
2. Make sure to turn on Bluetooth function on your computer.
3. Try a different surface. Remove metallic objects between the mouse and the computer.
4. Set mouse in pairing mode. Make sure it is discoverable on your computer and then complete pairing.
5. If it does not work after 10 seconds, repeat step 1 to 3.

Reconnection
Under Bluetooth connection (either Bluetooth 1 or 2) mouse can automatically reconnect to its last connected computer. If it fails, you can always re-pair again.

Note
The primary use case of the mouse is for computers, (desktop, laptop and tablet computers), connecting to a smartphone is not recommended.

Bluetooth

onn.EMOUSE or BT5.1 Mouse

BT Keyboard

Bluetooth: On

Turn Bluetooth Off

Now discoverable as "Karen's MacBook Pro"

Battery status

LED indicator

LED indicator

will start flashing green in pairing mode

1

封面朝上再彈簧折

P8 P7 P6 P5 P4 P3

封面 FCC hotline P1 P2 封底

2

封面

說明書折合完成
封面朝前折合後

3

封面局部示意

上下再對折

4

封面局部示意

封面朝前
再左右對折

5

封面局部示意

說明書折合完成

Project Name: 100027829(B2D_2.4G-BT Wireless Mouse) Walmart USA-onn Manual (QR code)_Outline_20220110(for越南包裝折法).ai		
REV. A	印刷順序：印單色，*雙面印刷再彈簧折	PROCESS COLORS K
DATE: 2022.01.10	紙質：雙交紙，60磅	
比例1:1 —— 裁切線 ----- 折線	尺寸： 未折合前-寬445.5 mm x 長105mm 折合後-寬37.125mm x 長52.5mm	
簽核：		製作者：Megan