

EXHIBIT 5

User's Manual

CAUTIONS AND INSTRUCTION

1. Use only on 110-120V, 60Hz.
2. Never disassemble or modify the lamp.
3. To prevent risk of fire, never install this device in the following fixtures:
 - a. Fixture on dimming circuits.
 - b. Emergency exit lights powered by direct current (DC).
4. To avoid risk of electronic shock----use only in dry locations.
5. This product may cause interference to the radio equipment and should no be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz.
6. This product may produce interference when using a T.V., radio or a wireless remote control. If interference should occur, move the lamp away form such equipment three feet or more, otherwise, plug the lamp or the receiver into a different outlet.
7. To prevent burns and avoid electric shock, please do not touch the bulb or cap during operation or immediately after switching off.

8. COMPLIANCE INFORMATION STATEMENT

Product Name: Energy Saving Lamp

Model Number: 70405, 70409, 70413, 50205, 50209, 70315, 70320, 80109(A), 80205(A)

Statement: This device complies with part 18 of FCC Rules operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.

2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This product may cause interference to the radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating between 0.45-30MHz.