

FIGURE 7  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
COVER REMOVED



FIGURE 8  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
LED BOARD FRONT




FIGURE 9  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
LED BOARD BACK



FIGURE 10  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
POWER BOARD FRONT




FIGURE 11  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
POWER BOARD BACK




FIGURE 12  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
RF BOARD FRONT 1




FIGURE 13  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
RF BOARD FRONT 2




FIGURE 14  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
RF BOARD BACK





FIGURE 15  
CYNC SHOPLIGHT  
(M/N: CFIXSHP46CDMAT)  
CHIP&CRYSTAL&ANTENNA



*---END OF APPENDIX II---*