

Installation Guide of PROSEO power metering in-wall outlet

In-wall outlet

COTLSTD2W1

COTLSTD2PM2W1

Input: 120VAC, 60Hz


Output: Max 15A General use, Max 1/2HP Motor

Operation temperature: -0°C~40°C

Indoor use only

Temper Resistant socket

Product



Accessories


Screw x4

Installation guide x1


Installation

Step 1: Before installation, power off your system to make sure no power in the line.

Step 2: Connect Line, Neutral, and Ground to the outlet separately. Install the outlet to the power box by screw.



Step 3: Install the bracket to the outlet by screw then install the front plate.



Step 4: Power on your system

Step 5: Commission the in-wall outlet with the host

Software key functionality

Factory Reset: Press and hold any on/off button for 15s till led indicator blink red and green by turn

LED language

LED Behavior	Status
Blue Blink	BLE broadcast
Green Blink	Identified
Green On Static	Outlet power on
Red On Static	Wi-Fi disconnected