




使用说明书 User Guide


初次使用

1. 充电盒开盖，一边耳机快闪，耳机自动开机并进入配对模式。
2. 打开手机蓝牙搜索并连接 [Sam&Johnny...].
3. 进入配对状态下，超过五分钟未连接时，耳机自动关机。



怎样舒适佩戴

1. 正确识别左右耳机。L适用于左耳，R适用于右耳。
2. 将耳机头放入耳道口，轻轻推入耳道。
3. 轻微旋转调整耳机的密封度和舒适度，获得最佳的音频体验。




暂停/播放音乐

1. 音乐播放/暂停时，单击触控区暂停/播放。
2. 切换歌曲时，长按 (L) 左耳2秒切换上一曲；长按 (R) 右耳2秒切换下一曲。




单耳使用

1. 打开充电舱，取出要使用的单边耳机，将其自动回连 (约5秒)。
2. 耳机提示 "Connected"，即可开始单耳使用。
3. 此时如需双耳使用，请从充电舱取出另一边耳机即可。




充电舱充电

1. 充电时双红灯慢闪，充满电时自灯熄灭。
2. 充电舱充电过程中，不会给耳机充电，充电舱充满电后自动跳转给耳机充电。



耳机充电

1. 耳机放进充电舱并关上盖子后，耳机进入充电状态。
2. 耳机充电时，充电舱白色指示灯慢闪5分钟。
3. 单边耳机充电，对应指示灯慢闪。




First Time Use

1. When the lid of the charging case is opened, one side of the headphones flashes rapidly. The headphones automatically power on and enter the pairing mode.
2. Turn on the Bluetooth on your mobile phone to search and connect. Follow [Sam&Johnny...].
3. When in the pairing state, the headphones will automatically power off if they are not connected for more than five minutes.



How To Wear Comfortably

1. Correctly identify the left and right earphones. L is suitable for the left ear and R for the right ear.
2. Insert the earphone head into the ear canal opening and gently push it into the ear canal.
3. Slightly rotate to adjust the sealing and comfort of the headphones for a better audio experience.




Play/Pause Music

1. When playing or pausing music, click the touch area to pause or play.
2. When switching songs, long press (L) the left ear for 2 seconds to switch the previous song; Long press (R) the right ear for 2 seconds to switch to the next song.




Single Ear Using

1. Open the charging case, take out the single earphone you want to use, and wait for it to reconnect automatically (about 5 seconds).
2. When the earphone prompts "Connected", you can start using it on one ear.
3. If you need to use both ears at this time, just remove the other earphone from the charging case.




Charging case charging

1. During the charging process of the charging box, the headphone is automatically charged after it is fully charged.
2. During the charging process in the charging case, the headphones will not be charged. Once the charging case is fully charged, it will automatically switch to charging the earphones.



Charging the headphone

1. After putting the headphones into the charging case and closing the lid, the headphones enter the charging state.
2. When the headphones are charging, the white indicator light in the charging case flashes slowly for 5 minutes.
3. When charging a single earphone, the corresponding indicator light flashes slowly.



清除耳机配对

清除耳机配对信息能解决大部分耳机连接不成功等问题。

将耳机置入充电舱内

1. 长按充电舱触摸键10秒，充电舱发射波形给耳机。
2. 这10秒内会出现大概4秒时双白灯慢闪两次，到大概10秒双白灯慢闪3次，表示完成所有操作。
3. 依据出厂设置后，重新连接手机。



充电盒触摸键

Clearing Of Earphone Pairing

Clearing the pairing information of headphones can solve most problems such as unsuccessful connection of headphones.

Put the headphones into the charging case

1. Press and hold the touch key of the charging case for 10 seconds, and the charging case will send a waveform to the headphones.
2. Press and hold for 4 seconds and the double white light will flash twice / to 10 seconds and the double white light will flash 3 times, indicating that all operations are completed.
3. After resetting, reconnect them to your phone.



Charging box button

触摸功能	上一曲	音乐播放时，L 长按 2 秒
	下一曲	音乐播放时，R 长按 2 秒
	音量加	R 双击（音乐播放时）
	音量减	L 双击（音乐播放时）
	接听电话	单击（来电时）
	挂断电话	单击（通话中）
	拒接电话	来电时，长按“挂断区”2秒可拒接电话（左右耳皆可）
	语音唤醒	任何状态下，L 单击后，即可启动语音助手
	播放/暂停	单击耳机触控区暂停/播放音乐（左右耳皆可）
	开机	长按 PC 触控键约 10 秒（指示灯：Power on）
	关机	长按 PC 触控键约 15 秒（指示灯：Power off）
	中断蓝牙电话	单击（来电时）

Touch Control	Previous song	Press and hold the L button for two seconds while music is playing
	Next song	Press and hold the R button for two seconds while music is playing
	Volume +	R button double-tap while music is playing
	Volume -	L button double-tap while music is playing
	Answer the phone	Click (incoming call)
	Hang up the phone	Click (on the call)
	Rejection of call	When a call comes, long press the "Touch case" for two seconds can reject the call (both right and left ear)
	Voice wake-up	In any state, LRM button three clicks, you can start the voice assistant
	Play/Pause	Click the touch area of the headset to pause/play (both left and right headphones can be used)
	Power on	Press and hold the power button for about two seconds (Prompt tone power on)
	Power off	Press and hold the power button for about two seconds (Prompt tone power off)
	Interrupting an ongoing call	Click (ongoing call)

产品规格

通话时间/音乐播放时间: 5-8小时

耳机电池: 46mAh x2

充电时间: 充电盒 <1.5 小时 耳机 <1 小时

充电输入: 5V/1A(TYPE-C)

单个耳机重量: 5.2-6.2克

充电盒重量: 60 克

双耳机尺寸: (长×宽×高) 3.8x1.7x1.8 厘米

充电盒尺寸: (长×宽×高) 6.5x4.1x3.3 厘米



Product Specifications

Talking Time/Music Play Time: 5-8hrs

Headphones Battery: 46mAh x2

Charging Time: Case <1.5hrs Headphones <1h

Charging Input: 5v/1A(TYPE-C)

Weight of individual headphones: 5.2-6.2g

Weight of charging box: 60 g

Headphone size: (LxWxH) 3.8x1.7x1.8cm

Charging Case size: (LxWxH) 6.5x4.1x3.3cm



问题:	解决方案:
双耳使用时，仅单耳有声音?	原因是双耳未配对成功，建议清除蓝牙配对信息，重新连接。
手机（其他设备）搜索不到蓝牙?	请将耳机放回充电舱，盖上舱盖后取出，关闭设备蓝牙并重新连接。
耳机连接配对成功，仅单耳有声音?	无声的耳机已关机，长按触控区 2 秒左右，听到提示音 power on 开机。
耳机自动断开连接?	耳机超出连接范围会断开连接，5分钟内回到蓝牙连接范围内自动重连。
耳机充不进去电?	原因充电仓没电，需要给充电仓充电。
充电舱满电，耳机充不进电?	充电舱指示灯以及耳机指示灯有异色，请清理干净。
通话音量小有杂音?	耳机有主副耳机之分，需切换成主机。
耳机信号断续?	将手机放在与耳机同侧，远离外界强信号干扰。

注：此手册内容仅供参考，如有更改恕不另行通知。

Problems:	Solution:
Does only one ear have the sound when using both ears?	It is recommended to clear the Bluetooth pairing information and reconnect, because the pair of earphones was not paired successfully.
Can mobile phone (other device) not find Bluetooth?	Please put the earphone back on the charging hatch cover and take it out from the hatch cover again, close the device Bluetooth and reconnect.
Headphones connected and paired successfully. Can only one ear sound?	Reason is that there is no sound headset power off, the long clicking centralization control about 2 seconds or so, said hear "power on" prompt boot up successfully.
Are earphones disconnected?	When the earphone is out of range, it will be disconnected and automatically reconnect within 5 minutes if return to the scope of Bluetooth.
Can the earphones not be charged?	Reason that charging compartment is out of power, so the charging compartment needs to be charged.
The charging case is fully charged, but the headphones can't be charged?	The headphone pin has poor contact. Check whether there are foreign objects in the thimble of the charging bin and the thimble of the headset, and clean it.
Is there noise when the call volume is low?	Headphone has the main and secondary headphone points, need to switch to the first.
Is the earphone signal intermittent?	Please the phone on the same side of the earphone and keep away from outside interference signals.

note: the contents of this manual are for reference only and are subject to change without notice.

安全信息 警告！

- 1.持续暴露于高噪音(超过85分贝)会导致听力永久受损。切勿长时间在高音量下收听。
- 2.电池不可自行更换，更换有爆炸危险。
- 3.使用通过CCC认证的对应规格电源适配器进行充电。
- 4.请勿私自篡改或拆卸耳机，否则会使保修失效。
- 5.注意您的周围环境，请不要在不安全的情况下使用耳机，例如驾驶车辆或者过马路等任何需要您注意周围环境的活动时。
- 6.请勿放置在高温环境中，有起火危险！



Safety information Warning!

1. Continued exposure to high noise levels (over 85 dB) can lead to permanent hearing damage. Do not listen at high volumes for long periods of time.
2. Batteries should not be replaced by yourself as there is a risk of explosion.
3. Use the corresponding specification power adapter certified by CCC for charging.
4. Do not tamper with or disassemble the headphones. Otherwise, the warranty will be voided.
5. Pay attention to your surroundings, please do not use the headset in unsafe conditions, such as driving a vehicle or crossing the street and any other activities that require you to pay attention to your surroundings.
6. Do not place in high temperature environment, there is a risk of fire!



ShenZhen
NAND SOUND ELECTRONICS
HEADPHONES

产品保修卡

若有售后需求，请联系客服
电话热线: 0755-29937058
制造商: 自然声电子(深圳)有限公司
地址: 广东省深圳市宝安区松岗街道九围社区九围第二工业区21号新艺工业园B1厂房二楼二楼

ShenZhen
NAND SOUND ELECTRONICS
HEADPHONES

Warranty Card

If you need after-sales service, please contact customer service.
Telephone hotline: 0755-29937058

Manufacturer:
Natural Sound Electronics (Shenzhen) CO., Ltd
Address:
2F, Building 1, the New Art Park Plant No. 21,
(Jiwei) Second Industrial Zone, Hangcheng Street,
Baoan District, Shenzhen

购买本产品时，请认真填写此卡，并予以妥善保存。

产品名称: _____

购买日期: _____

用户名: _____

联系电话: _____

用户地址: _____

经销单位: _____

联系电话: _____

经销地址: _____

盖章: _____

When purchasing this product, please fill in some cards carefully and keep them properly

Product Name: _____

Purchase date: _____

User Name: _____

Contact number: _____

User address: _____

Distributor: _____

Contact number: _____

Distribution address: _____

Signature: _____

FCC ID: PWK-HM10

FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.