



# BIGTIME™

## M U S C L E™

### R/C RADIO CONTROL

Keep these instructions for future reference: they contain important information.

**IMPORTANT: Please read all "Consumer Information" before operating your vehicle.**

#### CAUTION:

#### ELECTRICALLY OPERATED PRODUCT

Not recommended for children under 8 years of age. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

#### ADULT SUPERVISION REQUIRED.

Surfaces may become hot and cause burns if electronics get wet. Do not operate vehicle through water or snow.

#### Consumer Information:

**Note to Adults:** to ensure that the child's play is both safe and fun, please review all operating instructions and safety rules with your child.

#### CONTENTS

Vehicle  
Transmitter Controller  
Antenna for Transmitter Controller

#### Safety Tips

- NEVER drive your vehicle on streets! They're for real cars!
- DO NOT pick up vehicle while in motion.
- Avoid collisions with wall or hard surfaces.
- Keep fingers, hair and loose clothing away from tires and the wheel hubs while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries when not in use.
- Be sure to rest your vehicle for at least 5 minutes after every 15 minutes of operation.

#### BEFORE BATTERY INSTALLATION

Your new R/C is designed to work with standard 6 (six) "AA" alkaline batteries, sold separately. Controller is designed to work with a 9-volt alkaline battery, sold separately.

#### INSTALLING BATTERIES IN THE R/C

- 6 (six) "AA" Alkaline batteries (Not included)
1. Push the ON/OFF to "OFF" position on vehicle.
  2. Using a Phillips screwdriver (not included), to remove the battery compartment door underneath the vehicle. (See diagram 1)
  3. Insert the 6 "AA" alkaline batteries, with polarity (+/-) as shown inside battery compartment.
  4. Replace the battery compartment door and use Phillips screwdriver to lock the compartment door.

#### INSTALLING CONTROLLER –

#### 9 VOLT BATTERY

1. (one) 9V Alkaline battery (not included)
2. Open the battery cover as shown (See Diagram 2)
3. Install one 9V battery with polarity (+/-) as shown inside battery compartment.
3. Replace battery cover.

#### Battery Safety Information

- Insure that battery polarity is correct.
- Use only batteries of the type recommended (or equivalent).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove used-up batteries immediately. Remove batteries if vehicle will not be used for a long period of time to prevent possible leakage.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit terminals.
- Dispose of batteries safely. Do not dispose of batteries (or products containing non-replaceable batteries) in fire, as batteries may explode or leak.

#### QUICK TIPS


- When your vehicle starts to lose power, it may lose functions or performance. It's time for fresh batteries (or a recharge). Your vehicle's running time may change depending on your driving style.
- Radio interference can make your vehicle run badly. Interference can be caused by other R/C vehicles running on the same frequency; electrical wires, large buildings; or CB radios. Try to stay away from these!
- Point your transmitter controller antenna up – not down toward your vehicle. If your vehicle gets too far away, it won't work properly.
- Don't drive your vehicle in sand or through water or snow.
- Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries for storage.

#### Cleaning instruction:


To clean, wipe excess dirt from toy. Remove batteries first. Wipe toy clean with wet cloth using plain water. Wipe dry. **DO NOT IMMERSE IN WATER and DO NOT CLEAN VEHICLE WITH ANY CHEMICALS.** Let the toy completely dry up before putting batteries back into clean, dry battery compartment.



©2004 Jada Toys, Inc.  
City of Industry, CA 91748 USA  
DUB CITY® and R/C ROLLER\$™  
are trademarks of Jada Toys, Inc.  
All Rights Reserved.



(DIAGRAM 1)



(DIAGRAM 2)

#### Operations Tips:

Locate the transmitter antenna mount on the top of the transmitter. Insert the antenna into the mount opening and rotate in a clockwise direction until snug.

Car: ON / OFF switch located on the bottom of the car.

Transmitter: ON / OFF switch located on the front of the transmitter.

When you ready to run, please make sure push the ON / OFF switches to "ON" position on both. Go to get fun.