

Quick Start



AT&T Unite Explore

Set Up Your Mobile Hotspot


- ① Insert the pre-charged battery.
- ② Install the back cover.



Note: The mobile hotspot comes with a preinstalled SIM card.




Home Screen



BatteryBoost – Battery Backup on the Road

Use your mobile hotspot to charge your smartphone if its battery is low or out of power.

- ① Connect the BatteryBoost cable to the mobile hotspot's charging port.



- ② Connect your smartphone's charging cable to the BatteryBoost connector.
- ③ On the home screen, tap BatteryBoost.

Note: To avoid depleting the hotspot's battery, the hotspot stops boosting when its battery reaches 10%. To restart boosting, go to step ③.

Note: You can't charge the hotspot while its boosting your smartphone.



201-19573-01

Printed in China

Connect to the Internet

Turn on your Mobile Hotspot


- ① Press and release the power button.
 - ② Tap the Lock screen.
- The home screen displays.

Note: The home screen displays the hotspot's Wi-Fi network name and password.

On your laptop or other wireless devices

- ① Open your Wi-Fi/network connection manager.
- ② Connect your device to the hotspot with the Wi-Fi name and password.

Note: The AT&T Unite Explore home screen goes dark to save power. Press and release the power button to wake the screen.





Basic Connection and Device Options

Change WiFi settings

- Enable Guest Wi-Fi
- Change Main and Guest Wi-Fi names/passwords
- View connected devices
- Set maximum number of devices
- Read SMS messages

Change basic device settings


- Adjust screen timeout.
- Adjust data connection settings
- Update software
- Find hotspot's wireless number
- Set Wi-Fi range
- Hide Wi-Fi network name and password.



Wi-Fi Network Name and Password

Change Wi-Fi network name and password

- ① On the home screen, tap Wi-Fi > Main Wi-Fi.
- ② Tap Edit beside the name or password to be changed.
- ③ Tap Continue.



Hide password


To prevent unauthorized users from seeing the password and using the hotspot connection, hide the password on the home screen.

- ① On the home screen, tap Wi-Fi > Main Wi-Fi.
- ② Tap Wi-Fi Info on Home Screen and clear the Hide check box.

Advanced Settings – In Your Browser

Access device information and settings via the AT&T Unite Pro Manager page from your connected device.

- ① Connect a Wi-Fi device to your mobile hotspot.
- ② Go to <http://attwifimanager> in the connected device’s browser.
- ③ Login is **attadmin**.



Advanced Connection Options

You can set the AT&T Unite Pro to enable either 2.4 GHz or 5 GHz and a guest network.

Dual-Band Wi-Fi

For faster throughput on compatible devices, use 5 GHz Wi-Fi (this may use more standby power).

- ① On the home screen, tap **Wi-Fi > Band**.
- ②



Guest Wi-Fi with Timer

Let guests share your Wi-Fi. You set how long guest Wi-Fi stays active and the guest Wi-Fi password:

- ① On the home screen, tap **Wi-Fi > Guest Wi-Fi**.
- ② Tap **ON**. Guests can now choose the Guest network in their connection manager.
- ③ Select **Guest Timer** and specify the settings.



Network Indicators

Your 4G LTE wireless device will display one of the following network indicators to let you know which of AT&T’s wireless networks you are connected to.

-  Connected to AT&T’s 4G LTE network.
-  Connected to AT&T’s HSPA+network.



4G LTE not available everywhere. LTE is a trademark of ETSI. Learn more at att.com/network.

A network indicator does not necessarily mean that you will experience any particular upload or download data speeds. Actual upload and download data speeds depend upon a variety of factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at wireless.att.com/learn/articlesresources/wireless-terms.jsp Your AT&T Wireless Customer Agreement, Section 3.2 Where and How Does AT&T Service Work?

Advanced Connection Options (continued)

Block device access

To prevent a device from reconnecting to the mobile hotspot, add it to the hotspot’s blocked list:

- ① On the home screen, tap **Wi-Fi > Devices**.
- ② Select the device you want to block (there could be more than one page of connected devices).
- ③ Follow the displayed instructions to block the device.



Unblock a device

- ① On the home screen, tap **Wi-Fi > Devices > Blocked List**.
- ② Select the device you want to unblock, then tap **Unblock**.



Content Filtering Parental Controls

Set up content and website filtering using smart, easy-to-use controls.

- ① On the home screen, tap **Security > Parental Controls**.
- ② Select the level of parental controls..

Find More Information

On the Web

- Visit the interactive web tutorials available at att.com/devicehowto. Select brand: **AT&T**; model: **Unite Pro**.
- Additional support is available online, including device applications, troubleshooting and user forums at att.com/DeviceSupport.

On the phone

- Call AT&T Customer Care at **1-800-331-0500** for assistance with your AT&T service. When prompted, enter the 10-digit wireless phone number associated with your DataConnect service. The wireless phone number is found on the mobile hotspot at **Settings > About Device > Status**.