



Device basics



- 1 Charging/Notification light
- 2 NFC
- 3 Nano SIM/Memory card slot
- 4 Power key/Fingerprint sensor
- 5 Volume/Zoom key
- 6 Camera key
- 7 Charger/USB Type-C™ cable port

To insert the nano SIM card and the memory card



- Using your fingernail, drag out the SIM/Memory card holder.
- Firmly place the SIM card in the correct orientation in position (1) as shown in the illustration.
- Firmly place the memory card in the correct orientation in position (2) as shown in the illustration.
- Gently push the holder into the slot until it fits into place.

To turn on the device

It is important to use the USB Type-C™ cable (provided) when charging your device as other types of USB cables can damage your device. It is recommended to charge the battery for at least 30 minutes before you turn on the device for the first time.

- Press and hold down the power key until the device vibrates.
- Wait a moment for the device to start.

To activate the screen

- Briefly press the power key.

Screen protection

Before using your device, remove the protection film by pulling up on the protruding tab.

It is recommended to protect your device with a Sony branded screen cover or a protector intended for your Xperia™ model. The use of third party screen protection accessories may prevent your device from working correctly by covering sensors, lenses, speakers, or microphones and can invalidate the warranty.

Support for you

Access our support website directly on your device or visit support.sonymobile.com with any supported browser. Support options include User guides, downloadable content, troubleshooting tips and contact information.

Even if you don't have a network connection, you can access support contact information on your device. Depending on the country or region where you purchased your device, you can find this information directly in the Support application.

To access the Support application

- From your Home screen, tap.
- Find and tap.

For the best support available, we recommend connecting to the Internet when using the Support application.


Warranty, SAR and usage guidelines

For information about warranty, SAR (Specific Absorption Rate) and safety guidelines, please read the **Important information** provided under **Settings > About phone > Legal information** on your device.

Transferring contacts and content

If you need help to transfer contacts, messages, photos or other data from an old device to your new device, we recommend that you use the Xperia™ Transfer application. Visit www.sonymobile.com/xperiatransfer for more information.

To view the CE mark and FCC ID



- Using your fingernail, drag out the nano SIM/Memory card holder.
- Drag out the label tray in the same way.

To see the full text of the EU declaration of conformity, visit: <http://www.compliance.sony.de/>

To view the regulatory compliance mark

- Open the phone dialer, then enter *#07#.

Legal information

Publication number: 1305-1588.1
This Startup guide is published by Sony Mobile Communications Inc. or its local affiliated company, without any warranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications Inc. at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.
See regulatory information such as the device CE mark in the relevant label tray in the device.
All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. Visit www.sonymobile.com/global-en/legal/ for more information.
Manufacturer: Sony Mobile Communications Inc., 4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo, 140-0002, Japan. For EU product compliance: Sony Belgium, Bijlankhof van Sony Europe Limited, Da Vincilaan 7-D1, 1935 Zaventem, Belgium.
© 2016 Sony Mobile Communications Inc. All rights reserved.

Supported frequency bands

Some frequency bands might be turned off in certain markets or by certain operators.
F8331
UMTS HSPA+ 800 (Band VII), 800 (Band XIX), 850 (Band V), 900 (Band VIII), 1700 (Band IV), 1900 (Band II), 2100 (Band I) MHz GSM GPRS/EDGE 850, 900, 1800, 1900 MHz LTE (Bands 1, 2, 3, 4, 5, 7, 8, 12, 13, 17, 19, 20, 26, 28, 29, 32, 38, 39, 40, 41) WLAN 2.4G/5G, NFC

SONY

Startup guide

XPERIA
F8331

Sony Mobile Communications Inc.
4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo, 140-0002 Japan

