




**1. External Photograph of EUT**

**Brand Name: Sony**





**Brand Name: Sony**




**2. Photograph of Accessory****Brand Name: Sony**

| Specification of Accessory |             |                    |
|----------------------------|-------------|--------------------|
| AC Adapter 1               | Brand Name  | Sony               |
|                            | Model Name  | UCH20              |
|                            | Type Number | AC-0060-US         |
| AC Adapter 2               | Brand Name  | Sony               |
|                            | Model Name  | UCH20              |
|                            | Type Number | AC-0061-US         |
| Car Charger                | Brand Name  | Sony               |
|                            | Model Name  | AN400              |
|                            | Type Number | AC-0110 DC         |
| Battery 1                  | Brand Name  | Sony               |
|                            | Model Name  | LIS1618ERPC        |
| Battery 2                  | Brand Name  | Sony               |
|                            | Model Name  | GB-S10-385871-010H |
| Earphone                   | Brand Name  | Sony               |
|                            | Model Name  | MH410c             |
| USB Cable 1                | Brand Name  | Sony               |
|                            | Model Name  | EC803              |
| USB Cable 2                | Brand Name  | Sony               |
|                            | Model Name  | UCB16              |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



**Brand Name: Sony**



Brand Name: Sony

AC Adapter 1



Brand Name: Sony

AC Adapter 2



Brand Name: Sony

## Car Charger



Brand Name: Sony

Battery 1



Brand Name: Sony

Battery 2

