




**1. External Photograph of EUT**

**Brand Name: SONY / Type Name: PM-0382-BV**






**Brand Name: SONY / Type Name: PM-0382-BV**






**Brand Name: SONY / Type Name: PM-0382-BV**





**Brand Name: SONY / Type Name: PM-0382-BV**





Brand Name: SONY / Type Name: PM-0382-BV



**2. Photograph of Accessory****Brand Name: SONY / Type Name: PM-0382-BV**

| Specification of Accessory |            |             |
|----------------------------|------------|-------------|
| AC Adapter                 | Brand Name | SONY        |
|                            | Model Name | EP800       |
| Car Charger                | Brand Name | SONY        |
|                            | Model Name | AN400       |
| Battery                    | Brand Name | SONY        |
|                            | Model Name | LIS1551ERPC |
| Earphone                   | Brand Name | SONY        |
|                            | Model Name | MH410c      |
| USB Cable                  | Brand Name | SONY        |
|                            | Model Name | EC450       |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



Brand Name: SONY / Type Name: PM-0382-BV



Brand Name: SONY / Type Name: PM-0382-BV

AC Adapter




Brand Name: SONY / Type Name: PM-0382-BV

## Car Charger



Brand Name: SONY / Type Name: PM-0382-BV

Battery



Brand Name: SONY / Type Name: PM-0382-BV

Earphone



Brand Name: SONY / Type Name: PM-0382-BV

USB Cable

