

**1. External Photograph of EUT**

Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV





**Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV**





**Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV**





**Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV**



**Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV**




**2. Photograph of Accessory****Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV**

| Specification of Accessory |            |        |
|----------------------------|------------|--------|
| AC Adapter                 | Brand Name | SONY   |
|                            | Model Name | EP800  |
| Car Charger                | Brand Name | SONY   |
|                            | Model Name | AN400  |
| Battery                    | Brand Name | SONY   |
|                            | Model Name | BA900  |
| Earphone                   | Brand Name | SONY   |
|                            | Model Name | MH410c |
| USB Cable                  | Brand Name | SONY   |
|                            | Model Name | EC450  |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV

AC Adapter



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV


Car Charger






Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV

Battery



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV

Earphone



Brand Name: SONY / Model Name: D2105 / Type Name: PM-0671-BV

USB Cable

