



1. External Photograph of EUT

Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV




Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV






Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV






Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV



Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV



**2. Photograph of Accessory****Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV**

Specification of Accessory		
AC Adapter	Brand Name	SONY
	Model Name	EP800
Car Charger	Brand Name	SONY
	Model Name	AN400
Battery	Brand Name	SONY
	Model Name	LIS1502ERPC
Earphone	Brand Name	SONY
	Model Name	MH410c
USB Cable	Brand Name	SONY
	Model Name	AHAB EC450

Remark: For accessories equipped with this EUT, please refer to the following photos.



Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV



Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV

AC Adapter




Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV

Car Charger




Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV

Battery





Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV



Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV

Earphone



Brand Name: SONY / Model Name: D2303 / Type Name: PM-0722-BV

USB Cable

