



**1. External Photograph of EUT**

**Brand Name: SONY / Type Name: PM-0770-BV**






**Brand Name: SONY / Type Name: PM-0770-BV**






**Brand Name: SONY / Type Name: PM-0770-BV**






**Brand Name: SONY / Type Name: PM-0770-BV**





**Brand Name: SONY / Type Name: PM-0770-BV**



**2. Photograph of Accessory****Brand Name: SONY / Type Name: PM-0770-BV**

| Specification of Accessory |            |             |
|----------------------------|------------|-------------|
| AC Adapter                 | Brand Name | SONY        |
|                            | Model Name | EP800       |
| Car Charger                | Brand Name | SONY        |
|                            | Model Name | AN400       |
| Battery                    | Brand Name | SONY        |
|                            | Model Name | LIS1551ERPC |
| Earphone                   | Brand Name | SONY        |
|                            | Model Name | MH410c      |
| USB Cable                  | Brand Name | SONY        |
|                            | Model Name | AHAB EC450  |

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



**Brand Name: SONY / Type Name: PM-0770-BV**



Brand Name: SONY / Type Name: PM-0770-BV

AC Adapter




Brand Name: SONY / Type Name: PM-0770-BV


## Car Charger



Brand Name: SONY / Type Name: PM-0770-BV

Battery



**Brand Name: SONY / Type Name: PM-0770-BV**

Brand Name: SONY / Type Name: PM-0770-BV

Earphone



Brand Name: SONY / Type Name: PM-0770-BV

USB Cable

