



Important Information

Before you use your device, please read the *Important Information* provided in your device regarding warranty, safety and handling information.

Overview




- | | |
|--------------------------------|--------------------------------------|
| 1. Charging/Notification light | 10. Main microphone |
| 2. Proximity/Light sensor | 11. Wi-Fi/GPS/Bluetooth antenna area |
| 3. Ear speaker | 12. Main camera lens |
| 4. Front camera lens | 13. Main camera light |
| 5. Front camera light | 14. Second microphone |
| 6. Micro SIM card slot cover | 15. Headset jack |
| 7. Power key | 16. Port for charger/USB cable |
| 8. Volume/Zoom key | 17. Memory card slot cover |
| 9. Camera key | 18. NFC™ detection area |
| | 19. Speaker |


Assembly

To insert the micro SIM card

- ! If you insert a micro SIM card while the device is powered on, the device restarts automatically.



To insert a memory card




Basics

Turning on the device

Make sure that the battery is charged for at least 30 minutes before you turn on the device for the first time.

To turn on the device



- 1 Press and hold down the power key  until the device vibrates.
- 2 Wait a while for the device to start.

Waking up the screen

To activate the screen

- Briefly press the power key .

Setting up your device

Setup guide

The first time you start your device, a setup guide opens to help you configure basic settings, sign in to some accounts (for example, your Google™ account), and personalise your device. You can also manually access the setup guide at a later stage.

To access the setup guide manually

- 1 From the Home screen, tap .
- 2 Tap  > Setup guide.

Accessing settings

View and change settings for your device from the Settings menu. The Settings menu is accessible from both the Application screen and the Quick settings panel.

To access your device settings

- 1 From your Home screen, tap .
- 2 Find and tap .

Transferring your contacts

Xperia™ Transfer is an application within the PC Companion and the Sony Bridge for Mac computer programs that helps you to collect contacts from your old device and transfer them to your new device. Xperia™ Transfer supports several device brands, including iPhone, Samsung, HTC, BlackBerry, LG, and Nokia.

You need:

- An Internet-connected computer.
- A USB cable for your old device.
- A USB cable for your new Android™ device.
- Your old device.
- Your new Android™ device.

To transfer contacts to your new device

- 1 Search and download PC Companion (on a PC) or Bridge for Mac (on a Mac computer) from www.sonymobile.com if the application is not already installed.
- 2 After successful installation, open the PC Companion application or the Sony Bridge for Mac application, then click *Xperia™ Transfer* and follow the relevant instructions to transfer your contacts.

Finding your way



Using the keys




-  **Back navigation key**
 - Go back to the previous screen within an application or close the application.
-  **Home navigation key**
 - Exit an application and go back to the Home screen.
-  **Task navigation key**
 - Open the recently used applications window and the small apps bar.
-  **Application screen**
 - Open the Application screen.

Basic applications and settings

-  Make phone calls by dialling the number manually or by using the smart dial function.
-  Use the Messaging application to send and receive text and multimedia messages.
-  Go to Google Play™ to download free and paid applications for your device.
-  Optimise the device settings to suit your own requirements.

Status and notifications

To open or close the Notification panel



- Drag down two fingers instead of one to open the Quick settings panel instead.

Support on the web



Visit www.sonymobile.com/support to access a range of support options for your device, including downloads, troubleshooting tips and a User guide.

Legal information

Sony D2533

Publication number: 1285-9771.1

This Startup guide is published by Sony Mobile Communications AB or its local affiliated company, without any warranty. Improvements and changes to this Startup guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this Startup guide. All illustrations are for illustration only and may not accurately depict the actual device.


See regulatory information such as the CE mark in the relevant label tray in the device.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved. Visit www.sonymobile.com/us/legal/ for more information.

Product compliance: This product has been manufactured by or on behalf of Sony Mobile Communications, Mobilvägen, SE-221 88 Lund, Sweden. Inquiries related to product compliance based on national legislation shall be addressed to Sony Mobile Quality Officer, Sony Mobile Communications AB, Mobilvägen, SE-221 88 Lund, Sweden. For any service or guarantee matters, please refer to the contact details provided in the separate service or guarantee documents.

© 2014 Sony Mobile Communications AB. All rights reserved.

To view the CE mark and the FCC ID



- 1 Detach the memory card slot cover.
- 2 Insert the tip of an unfolded paper clip (or a similar object with a long, fine tip) into the hole in the label tray, then drag the tray outwards. The information is displayed on the tray.

SONY®

Startup guide

Xperia™ C3
D2533

XPERIA

Sony Mobile Communications AB
SE-221 88 Lund, Sweden
www.sonymobile.com