

Radio Transmitter Model 1010 ZeePad

Instruction Manual

Notice to User :

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no grantee that interference will not occur in a particular installation.

If this equipment dose cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Notice :

The changes or modifications not expressly approved by GOOD MIND INDUSTRIES CO., LTD., could void the user's authority to operate the equipment.

The user should not modify or change this equipment without written approval from GOOD MIND INDUSTRIES CO., LTD. Modification could void authority to use this equipment.

Operating Procedure :

A. Install the Media Access

1. Turn on the computer.
2. Disconnect, or disable the sound card installed in the computer.
3. Restart the computer.
4. Start Windows 98 or Windows NT4.0
5. Click Windows Explorer
6. Insert the software diskette 1 into drive A.
7. Click on 3 1/2 floppy [A :]
8. Double click at Setup.exe to start the installation.
9. Insert the software diskette 2 into drive A as instructed.

10. After the message of the completion of the installation, click FINISH and go back to Windows Explorer
11. Click CLOSE to exit Windows Explorer

B. Start the Media Access

12. Click START again, and , then, click PROGRAMS. You will find a list of programs.
13. Select the program : Media Access GMI and Media Access appears.
14. Click at Media Access to start the program. An icon of M/A shows on the right corner in the taskbar.

C. Connect the ZeePad

15. Connect the ZeePad to the USB port of your computer via a USB cable.
16. Set the FM transmitting frequency within 90-106 MHz $\pm$ 1MHz by setting the adjustment device which can be accessed via bottom of the unit.
17. Press the black button on the ZeePad and, immediately, access to radiocom.com on the web.