



User manual

Model:78560

Brand:Summer

Duet Stroller Speaker

INSTRUCTION MANUAL

Important Safety Instructions


1. Read Instructions – All the safety and operation instructions should be read before operating product.
2. Retain Instructions – The safety and operating instructions should be retained for future reference.
3. Heed Warnings – All warnings on the product, instructions and packaging should be adhered to.
4. Follow Instructions – All operating and use instructions should be followed.
5. Cleaning - Do not clean with product plugged in and charging. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. Attachments – Do not use attachments that did not come included with this product as they may cause hazards or damage to the product.
7. Water Resistance – This product is water resistant, not waterproof. Do not submerge in water.
8. Charging – Only charge using included cable.
9. Service – Do not attempt to service yourself as opening this product could result in electric shock.
10. Damage – Discontinue use of any part of this product (cord or speaker) if there are any signs of damage.
11. Replacement Parts – When replacement parts are required, only use certified replacements from Summer Infant.
Part substitutions may result in fire, electric shock or other hazards.

⚠ WARNING

- When plugged into charging cord do not touch the exposed end.
- Do not submerge in water.
- Keep away from heat sources (such as stoves, radiators, etc.)
- This product is not a toy. Do not allow children to play with it.
- Do not continue charging the battery if it does not reach full charge within the 10 hours.
Overcharging may cause the battery to become hot, rupture, or ignite.
- If the battery begins to leak, do not allow the liquid to come in contact with your skin or eyes.
If contact has been made, wash the affected area with plenty of water and seek medical advice immediately.
- This product contains magnets which can be harmful to pacemaker wearers.

CAUTION: Changes or modifications not expressly approved by Summer Infant, Inc. may void the user's authority to operate this equipment.

COMPONENTS



SET UP

Pairing your wireless device: iPhone®/iPad®/iPod touch®
(Note: ios 4.0 or higher is required.)

1. To power the Duet wireless speaker on press and hold the power button for 4-5 seconds until you hear the tone.
2. To pair your Apple device, go to SETTINGS -> BLUETOOTH. Slide the Bluetooth slider to the "ON" position. Your Apple device will automatically search for nearby Bluetooth devices.
3. On your Apple devices screen you will see "SUMMER" as a Bluetooth option. Tap it to select and pair.
4. Once your Apple device has been paired once, it will automatically pair in the future if your Bluetooth on your Apple device is turned "ON".

Other devices:

1. To power the Duet wireless speaker on press and hold the power button for 4-5 seconds until you hear the tone.
2. To pair your device, go to its Bluetooth setting and turn it to the "ON" position. Your device will automatically search for nearby Bluetooth devices.
3. On your devices screen you will see "SUMMER" as a Bluetooth option. Tap it to select and pair.
4. Once your device has been paired once, it will automatically pair in the future if your Bluetooth on your Android device is turned "ON".

Listening to music:

1. Open your Bluetooth devices media player or a music streaming app.
2. You are able to control playback and volume directly from your connected Bluetooth device or the buttons on the Duet wireless speaker.

iPhone, iPad and iPod touch are trademarks of Apple, Inc., registered in the U.S.A.

Using the phone:


1. When you have an incoming call the Duet wireless speaker will play your phones ringtone. To answer the call, you are able to accept on your connected Bluetooth device or by using the Call receive button on Duet wireless speaker.
2. To end the call, press End on your connected Bluetooth device or press the call receive/terminate button.

Note: Phone calls will default to the Duet wireless speaker. You will need to use your connected Bluetooth device to switch to its internal speaker if privacy is needed.

Charging:

1. To charge the Duet wireless speaker, use the included USB charging cable and plug into an available USB port on a computer or a 5V 500mA USB adapter (not included).
2. The Duet wireless speaker's red LED will remain lit or flash until the battery is fully charged.

Recommended position for placement on a flat surface:



FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The distance between user and products should be no less than 20cm

The device is used on bicycle or similar situation , the device can not used as portable device