

PULSE 2

BLUESOUND®



© Bluesound International. Bluesound, the stylized wordmark and "B" logotype, the phrase "HiFi for a wireless generation", PULSE 2 and all other Bluesound product names and taglines are trademarks or registered trademarks of Bluesound International, a division of Lenbrook Industries Limited. All other logos and services are trademarks or service marks of their respective owners.

15-003

Quick Setup Guide

bluesound.com

Included Accessories



120V AC Power Cord



230V AC Power Cord



Ethernet Cable



Mini Jack to Toslink Adaptor


PULSE 2

All-in-one
Wireless Streaming
Music System

English	4
Français	8
Español	9
Italiano	10
Português	11
Deutsch	12
Nederlands	13
Svenska	14
Русский	15

1

CONNECT ZO POWER



- A Select the AC Power Cord appropriate for your region and plug it into the Player, and then into your wall outlet.
- B The PULSE 2's LED button should turn Solid Green, indicating that the player is in Hotspot Mode and ready to be added to your home WiFi network.

Never force a power cord into a wall outlet. An adaptor may be necessary in certain regions.

2

CONNECT TO WiFi




- A On your tablet or smartphone, **look for the WiFi network (hotspot) matching your PULSE 2's unique network ID**, and join it. The network ID is listed as the product name (i.e. PULSE 2) immediately followed by the last four digits in the MAC (Machine Access Control) address (example: **PULSE2-001A**). The full 12-digit MAC address is printed on a sticker on the back panel of your Player.
- B Open a web browser on your tablet or smartphone and enter **setup.bluesound.com**, and press "Go". A control panel page should then appear.
- C From the main menu displayed, select **Configure WiFi**.
- D Select **your home WiFi Network** from the **Configure Wireless** drop down menu.
- E Enter your home network's **Wireless Password** in the field provided (if it is a protected network).
- F Select a **Room Name** from the drop down list, or create a customized Room name in the field provided.
- G Press **Update** and wait for the Player's light to turn solid blue, indicating that the Player has successfully joined your home WiFi network.
- H Repeat steps A-G for each additional Bluesound Player.
- I **Reselect your home WiFi network** from your tablet or smartphone's **main network settings**.

Alternatively, the PULSE 2 can be connected directly to your wired home network or router using the Ethernet cable provided.

To see an instructional video on WiFi Setup, please visit www.bluesound.com

3

DOWNLOAD THE APP



All Bluesound Controller Apps for Apple iOS devices (iPhone, iPad, iPod), Android devices, Kindle Fire, and Windows or Mac desktops are available for download at www.bluesound.com/downloads

Congratulations, your Player setup is complete!

It's time to connect your music. Launch the App for the following playback options.



4

CONNECT TO MUSIC



Your Music : To play music stored on a computer or NAS device, open the Navigation Drawer by tapping the  in the App, choose **Configure Player** from the menu, and select **Configure Network Shares**. Follow the screen prompts, and open every Room in your home to your entire digital music library.



Internet Radio : Simply select **TuneIn** from the **Music Services** menu, and find your favorite radio station. Or, explore and discover the thousands of radio stations streaming live 24/7 from anywhere on the planet via **TuneIn**.

For detailed information, please visit www.bluesound.com