


LTE Band 38 - Ant 6, Channel Bandwidth: 10 MHz



CH 37800 (2575 MHz)




CH 38000 (2595 MHz)




CH 38200 (2615 MHz)

Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 38 - Ant 6, Channel Bandwidth: 10 MHz




LTE Band 38 - Ant 6, Channel Bandwidth: 15 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 38 - Ant 6, Channel Bandwidth: 15 MHz



LTE Band 38 - Ant 6, Channel Bandwidth: 20 MHz




Note: The signal at 9 kHz is IF signal from spectrum analyzer.

LTE Band 38 - Ant 6, Channel Bandwidth: 20 MHz



7.5.14 LTE Band 41


LTE Band 41 - Ant 5_PC2, Channel Bandwidth: 5 MHz



LTE Band 41 - Ant 5_PC2, Channel Bandwidth: 5 MHz




LTE Band 41 - Ant 5_PC2, Channel Bandwidth: 10 MHz



Note: The signal at 9 kHz is IF signal from spectrum analyzer.


LTE Band 41 - Ant 5_PC2, Channel Bandwidth: 10 MHz



1RB CH 39700 (2501 MHz)

1RB CH 0 (2685 MHz)

LTE Band 41 - Ant 5_PC2, Channel Bandwidth: 15 MHz



Note: The signal at 9 kHz is IF signal from spectrum analyzer.